

GROUNDS MOWERS

•

Models

GI800SS,GI800KSS, GI890,GI890K,GI890V,G2000CII (HYDRAULIC DRIVE MOWERS)

Parts List



TABLE OF CONTENTS

KOHLER ENGINE PARTS
ENGINE AND ATTACHING PARTS (BRIGGS AND STRATTON I/C
ENGINE AND ATTACHING PARTS (BRIGGS AND STRATTON VA
ELECTRIC CLUTCH
FIJEL SYSTEM
BASE ASSEMBLY (G1890,G1890K,G1890V)
BASE ASSEMBLY (G1800SS, G1800KSS)
BASE ASSEMBLY (G2000CII)
BODY ASSEMBLY (G1800SS, G1800KSS, G1890, G1890K, G1890V
BODY ASSEMBLY (G2000CII)
SEAT LID AND STEERING
-SINGLE TAIL WHEEL
DUAL TAIL WHEEL
PUMP DRIVE (G1800SS,G1800KSS)
PUMP DRIVE (G2000CII)
PUMP DRIVE CROSS SHAFT (G1890,G1890K,GL890V)
DRIVE ASSEMBLY R.H. (G1890,G1890K,G1890Ý)
DRIVE ASSEMBLY L.H. (G1890,G1890K,G1890V)
STEERING CABLE KIT (G1890,G1890K,G1890V)
BRAKE ASSEMBLY (G1800SS,G1800KSS)
WHEEL MOTOR AND PUMP (GI800SS, GI800KSS)
WHEEL MOTOR AND PUMP (G2000CII)
HYDRAULIC SYSTEM (GI890,GI890K,GI890V)
HYDRAULIC/LIFT
ELECTRIC DECK LIFT (WINCH) INCLUDES WIRING DIAGRAM
WIRING DIAGRAM
DECALS

	· A4
ODEL)	. A6
UARD MODEL)	
	. A8
	8 8
••••••	A10
• • • • • • • • • • • • • • • • • • • •	A12
	AI2
••••••	AI4
• • • • • • • • • • • • • • • • • • • •	B2
	B4
••••••	86
	B6
	B8
ن • • • • • • • • • • • • • • • • • • •	B8
	B10
	B12
•••••••••••••••••••••••••••••••••••••••	B14
• • • • • • • • • • • • • • • • • • • •	. 02
·····	. C2
·····	. (4
1	: C6
· · · · · · · · · · · · · · · · · · ·	. (8
•••••••	C10
	CI2
·	CI4
	D7

(2)

				4 2 ·	
		•••	•		ENGINE AND ATTACHING P KOHLER
				x	
(15)	6		REF.	PART NO.	DESCRIPTION
			1	C 41676	ENGINE - Kohler Model M18QS, Spec. No: 2
		· •	1	C 41677	ENGINE - Kohler Model M200S, Spec. No
	φ		. 2	C 37561`	DUCT - air (side exhaust) (2000)
	15		2	C 42050	DUCT - air (rear exhaust)
	P (a)).		3	C 42055	CLAMP - pipe (rear exhaust)
tail	(0))		4	C 42054	PIPE - rear exhaust (rear exhaust)
1188	\mathcal{O}	-,	5	121 21	BOLT - 1/4" - 20 flange lock
$ \langle \nabla w_{2} \rangle >$	\mathbf{y}		. 6	C 37536	BRACKET - wire standoff
		· . '	7	C 37563	SPACER
			8	C 41015	KEY - 1/4," x 1/4" x 1"
	+-(1)		9	C 37564	PULLEY - drive (includes 83-46 set screw
			9	C 37565	PULLEY - drive, double (2000) (includes 8
· V Or P	· •		10	C 37540	RETAINER' - starter wire
m m	-i		11	C 37541	ELBOW - street 1/8"
ND Y	(10) (10) (10)		12	C 37531	UNIT - oil sending
(20)			13	C 42240	HARNESS - wire
	i and		14	. C 37566	PRECLEANER
	(4) \	0	15	C 37567	

15

16

17

18

19 20

21

22

23

24

24

1 22

,

C 37567

C 37568

C 37546

221- 376

C 37548

11,3- 122

131- 911

C 37819

C 37820

°C 39403

C 40893

NSS


5

61

(2)

PARTS

REQ'D 24532 (18 hp) (1890K, 1800KSS) No. 49517 (20 hp) (2000). 1 7 UAR 2 w) (1800, 1890) shown 83-46 set screw) PRECLEANER FILTER - air FILTER - oil PLUG - pipe 3/8" ELBOW - pipe 3/8" NIPPLE - pipe 3/8" x 4" BOLT - 5/16" 18 x 1-1/2" NUT - 5/16" -18 SCREW - #12 x 1/2" MUFFLER - exhaust (rear exhaust) MUFFLER - exhaust (side exhaust) obtain from local Kohler dealer



ENGINE AND ATTACHING PARTS

BRIGGS AND STRATTON (I C MODEL)

منيم.

DESCRIPTION REC'D *ENGINE - Briggs and Stratton, model 422447, Spec. No. 1277 1 (18 hp) (18005S, 1630) 1 DUCT - sir 1 BOLT - sir 1 WID - 6/16" - 18 × 1-14". 4 PULG - pipe 3/8". UAR PULG - pipe 3/8". UAR PULG - pipe 3/8". UAR PULG - pipe 1/2" - 20 UAR SHAFT - stub 1 KEY - 1/4" × 1/4" × 1/4" 1 PULLEY - drive (use 83-55 set screw) 1 RETAINER - starter cable 2 ELBOW - street 1/8" 1 MIT - oil - sonding 1 BOLT - 1/4" - 20 flange lock 7 CABLE - throttle 1 SCREW - #12 × 1/2" UAR NIPPLE - 3/8" × 3-1/2" UAR NIPPLE - jop 3/8" x 3-1/2" UAR NIPPLE - sings & Stratton Model 350447, type 0124 (18 hp) (1890V) 1 IENGINE AND ATTACHING PARTS 2 BOLT - 5/16" - 18 x 1-1/4" 4 NUT - 5/16" - 18 x 1-1/4" 1 NPELE - B	(See your local engine dealer	for other parts a	and repairs)	• E	(,	· í
(18 hp) (1800SS, 1890) 1 ELBOW - 3/8" UAR BOLT - 5/16" - 18 x 1-1/4" 4 NUT - 5/16" - 18 x 1-1/4" 4 PLUG - pipe 3/8" UAR PLUG - pipe 3/8" UAR SHAFT - stub 1 KFY - 1/4" x 1/4" x 1" UAR PULGY - dive (use 83-55 set screw) 1 RETAINER - starter cable 2 ELBOW - street 1/8" 1 UNT - oil sending 1 HARNESS - wire. 1 PRECLEANER - Fair - 4 1 FILTER - air - 4 1 SCREW - #12 x 1/2" 4 SCREW - #12 x 1/2" 4 NIPPLE - oipe 3/8" x 3-1/2" 1 NIPPLE - bipe 3/8" x 3-1/2" 1 VOCKWASHER 2 BOLT - 3/6" - 16 x 1" 2 VORKMER 2 BOLT - 5/16" - 18 x 1-1/4" 1 NIPPLE - 3/8" x 4" 1 UAR 1 NIPPLE - 5/16" - 18 x 1-1/4" 1 BOLT - 5/16" - 18 x 1-1/4" 1 BOLT - 5/16" - 18 x 1-1/4" NUT - 5/16" - 18	DESCRIPTION	•	•		•	REQ'D	1 1 1
DUCT - air. 1 ELBOW - 3/8". UAR BOLT - 5/16" - 18 x 1-1/4". 4 PLUG - pipe 3/8". UAR PLUG - pipe 3/8". UAR SHAFT - stub 1 KEY - 1/4" x 1/4" x 1". 1 PULLEY - drive (use 83-55 set screw). 1 RETAINER - starter cable 2 ELBOW - street 1/8". 1 HARNESS - wire. 1 PRECLEANER - 1 FILTER - air 1 FILTER - oil 1 BOLT - 1/4" - 20 flange lock 7 CABLE - throttle 1 SCREW - #12 x 1/2" UAR NIFPLE - 3/8" x 4" 1 LOCKWASHER 2 BOLT - 3/6" - 16 x 1" 2 ENGINE AND ATTACHING PARTS 2 BRIGGS & STRATTON VANGUARD MODEL 1 · LOCKWASHER 2 BOLT - 5/16" - 18 x 1-1/4". 4 NUT - 5/16" - 18 kange lock 5 CLIP - '16" - 18 x 1* 1 PIEE - exhaust 1 BOLT - 5/16" - 18 x 1* 1 DUCT -	(18 hp) (1800SS, 1890)				•	1	
BOLT - (5/16)" - 18 × 1-1/4" 4 PUUG - pipe 3/8" 4 PUUG - pipe 3/8" 4 PUUG - pipe 3/8" 4 SHAFT - stub 1 SHAFT - stub 1 PULEY - drive (use 83-55 set screw). 1 RETAINER - starter cable 2 LEBOW - street 1/8" 1 UNIT - oil sending 1 HARNESS - wira. 1 FILTER - air 1 FILTER - oil 1 BOLT - 1/4" - 20 flange lock 7 CABLE - throttle 2 SCREW - #12 x 1/2" 4 NIPPLE - 3/8" x 4" 1 LOCKWASHER 2 BOLT - 3/8" - 16 x 1" 2 ENGINE AND ATTACHING PARTS 2 BRIGGS & STRATTON VÁNGUARD MODEL 1 · LOCKWASHER 2 BOLT - 5/16" - 18 x 1-1/4" 4 NUT - 5/16" - 18 x 1'1/4" 1	DUCT - air					1	
NUT- 5/16" - 18 4 PLUG - pipe 3/8" UAR PLUG - pipe 1/2" - 20 UAR SHAFT - stub 1 KEY 1/4" x 1/4" x 1" 1 PULE - drive (use 83-55 set screw) 1 RETAINER - stater cable 2 LEBOW - street 1/8" 1 VINT - oil sending 1 HARNESS - wire 1 FILTER - air 4 1 FILTER - oil 1 BOLT - 1/4" × 20 flange lock 7 CABLE - throttle 1 SCREW - #12 x 1/2" 4 NIPPLE - pipe 3/8" x 3-1/2" 1 LOCKWASHER 2 BOLT - 3/8" - 16 x 1" 2 ENGINE AND ATTACHING PARTS 1 BRIGGS & STRATTON VÁNGUARD MODEL 1 (See your local engine dealer for other parts and repairs) 1 ENGINE - Briggs & Stratton Model 350447, type 0124 (18 hp) (1890V) : 1 ELEMENT - air cleaner 1 PRC - exhaust 1 BOLT - 5/16" - 18 x 1-1/4" 4 NUT - 5/16" - 18 x 1-1/4" 4 NUT - outical engine lock 5	ELBOW - 3/8''	• • • • • • • • • • • • • • •		• • • • • •			4.
PLUG - pipe 1/2" - 20 UAR SHAFT - stub 1 KEY - 1/4" x 1/4" x 1" 1 NET - stub 1 PULLEY - drive (use 83-55 set screw) 1 RETAINER - starter cable 2 ELBOW - street 1/8" 1 UNIT - oil sending 1 HARNESS - wire 1 PRECLEANER 1 FLITER - air 1 FLITER - air 1 GABLE - choke 1 CABLE - throttle 1 SCREW - #12 x 1/2" 4 NIPPLE - pipe 3/8" x 3-1/2" 4 NIPPLE - 3/8" x 4" 1 LOCKWASHER 2 BOLT - 3/8" art 1/2" 4 NIPPLE - site 3/8" x 3-1/2" 4 NIPPLE - site 3/8" x 4" 1 LOCKWASHER 2 BOLT - 3/8" art 1/4" 2 BOLT - 5/16" - 16 x 1" 1 IBUPCORT - air cleaner 1 PHE - claNER 1 BOLT - 5/16" - 18 x 1-1/4" 4 NUT - 5/16" - 18 x 1-1/4" 1 NUT - 5/16" - 18 x 1-1/4" <	NUT - 5/16" - 18					-	÷
SHAFT - stub 1 VEY - 1/4" × 1/4" × 1" 1 PULLEY - drive (use 83-55 set screw) 1 RETAINER - starter cable 2 LBOW - street 1/8" 1 VINT - oil sending 1 HARNESS - wire 1 PRECLEANER 1 FLTER - air 1 CABLE - chocke 1 CABLE - thortte 1 SCREW - #12 × 1/2" UAR NIPPLE - 3/8" × 4" 1 LOCKWASHER 2 BOLT - 3/8" - 16 x 1" 2 ENGINE AND ATTACHING PARTS 1 BRIGGS & STRATTON VANGUARD MODEL 1 PRE-CLEANER 2 BOLT - 5/16" - 18 x 1-1/4" 1 NUT - 5/16" - 18 k 1-1/4" 1 BOLT - 5/16" - 18 k 11 1 DUCT - muffler, upper 1 DUCT	PLUG pipe 3/8"	• • • • • • • • • • • • • • • • • • •	•••••				
PULLEY - drive (use 83-55 set screw). 1 RETAINER - starter cable 2 LBOW - street 1/8" 1 UNIT - oil sending 1 HARNESS - wire 1 PRECLEANER 1 FILTER - air 1 FILTER - air 1 FILTER - air 1 FILTER - air 1 SCREW - #12 x 1/2" UAR NIPPLE - Jipe 3/8" x 3-1/2" UAR NIPPLE - Jipe 3/8" x 4" 1 LOCKWASHER 2 BOLT - 3/8" x 4" 1 LOCKWASHER 2 BOLT - 3/8" x 4" 1 LOCKWASHER 2 BOLT - 5/16", -16 x 1" 2 ENGINE - Briggs & STRATTON VANGUARD MODEL 1 * (See your local engine dealer for other parts and repairs) 1 ELEMENT - air cleanet 1 PRECLEANER 1 BOLT - 5/16", -18 x 1-1/4". 4 NUT - 5/16", -18 x 1' 1 DUCT - mulfler, upper 1 DUCT - mulfler, upper 1 DUCT - mulfler, upper 1	SHAFT - stub			· · · · · · · · · · · · · · · · · · ·		1	ĺ Ì
RETAINER - starter cable 2 ELBOW - street 1/8" 1 UNIT - oil sending 1 HARNESS - wire 1 FILTER - air 1 FILTER - oil 1 BOLT - 1/4" - 20 flange lock 7 CABLE - choke 1 CABLE - throttle 1 SCREW - #12 x 1/2" 4 NIPPLE - pipe 3/8" x 3-1/2" UAR NIPPLE - 3/8" x 4" 1 LOCKWASHER 2 BOLT - 3/8" - 16 x 1" 2 ENGINE AND ATTACHING PARTS 2 BRIGGS & STRATTON VANGUARD MODEL 1 · See your local engine dealer for other parts and repairs) 1 ELMEMT - air cleaner 1 PRE-CLEANER 1 BOLT - 5/16" - 18 x 1-1/4" 4 NUT - 5/16" - 18 x 1-1/4" 1 BOLT - 5/16" - 18 x 1-1/4" 1 BOLT - 5/16" - 18 x 1-1/4" 1 DUCT - muffler, upper 1 DUCT - muffler, upper 1 DUCT - muffler, upper 1 DUCT - dott front (use C45111). 1 SUPPORT - douc	KEY - 1/4" x 1/4" x 1"					1	<u>`</u>
ELBOW - street 1/8" 1 UNIT - oil isending 1 PRECLEANER 1 FILTER - air 1 CABLE - choke 1 CABLE - bipe 3/8" x 3-1/2" UAR NIPPLE - 3/8" x 4" 1 LOCKWASHER 2 BOLT - 3/8" - 16 x 1" 2 BOLT - 5/16" - 18 x 1-1/4" 1 BOLT - 5/16" - 18 x 1-1/4" 1 NUT - 5/16" - 18 x 1-1/4" 1 NUT - 5/16" - 18 x 1" 1 DUCT - muffler, upper 1 DUCT - muffler, upper 1 DUCT - muffler, upper 1						1	A
HARNESS - wire. 1 PRECLEANER 1 FILTER - oil 1 FILTER - oil 1 BOLT - 1/4" - 20 flange lock 7 CABLE - choke 1 CABLE - throttle 1 SCREW - #12 x 1/2" 4 NIPPLE - oipe 3/8" x 3-1/2" UAR NIPPLE - 3/8" x 4" 1 LOCKWASHER 2 BOLT - 3/8" - 16 x 1" 2 BOLT - 3/8" - 16 x 1" 2 BOLT - 3/8" - 16 x 1" 2 ENGINE AND ATTACHING PARTS 3 BRIGGS & STRATTON VÁNGUARD MODEL 2 'See your local engine dealer for other parts and repairs) 1 ENGINE - Briggs & Stratton Model 350447, type 0124 (18 hp) (1890V) 1 PHE- exhaust 1 BOLT - 5/16" - 18 x 1-1/4" 4 NUT - 5/16" - 18 x 1-1/4" 4 DUCT - battom 1 BRICKET - exhaust pipe 1 BOLT - 5/16" - 18 x 1" 1 DUCT - battom 1 SUPPORT - duct front (use C45111) 1 SUPPORT - duct front (use C45111) 1 <	ELBOW - street 1/8"					1	
PRECLEANER 1 FILTER air 1 FILTER air 1 BOLT - 1/4". 20 flange lock 1 CABLE - choke 1 CABLE - throttle 1 SCREW #12 x 1/2" 4 NIPPLE - pipe 3/8" x 3-1/2" UAR NIPPLE 3/8" x 4" 1 LOCKWASHER 2 BOLT - 3/8" - 16 x 1" 2 BOLT - 3/8" - 16 x 1" 2 ENGINE AND ATTACHING PARTS 3 BRIGGS & STRATTON VÁNGUARD MODEL 1 (See your local engine dealer for other parts and repairs) 1 ENGINE - Briggs & Stratton Model 350447, type 0124 (18 hp) (1890V) 1 ELEMENT - air cleaner 1 PRE-CLEANER 1 BOLT - 5/16" - 18 x 1-1/4" 4 NUT - 5/16" - 18 ka 1-1/4" 1 DUCT - bottom 1 BRACKET - exhaust pipe 1 BOLT - 5/16" - 18 x 1" 1 DUCT - bottom 1 SUPPORT - duct front (use C45111) 1 SUPPORT - duct front (use C45111) 1 SUPPORT - duct front (use C45111) 1 </th <th></th> <th>• • • <u>.</u>• • • • • • • • • •</th> <th> • • • • • • • •</th> <th>· · · · · · ·</th> <th></th> <th>1</th> <th>•</th>		• • • <u>.</u> • • • • • • • • • •	• • • • • • • •	· · · · · · ·		1	•
FILTER - air 1 BOLT - 1/4". 20 flange lock 1 BOLT - 1/4". 2 0 flange lock 1 CABLE - choke 1 CABLE - throttle 1 SCREW - #12 x 1/2" 4 NIPPLE - 3/8" x 4" 1 LOCKWASHER 2 BOLT - 3/8" x 4" 1 LOCKWASHER 2 BOLT - 3/8" - 16 x 1" 2 BOLT - 3/8" - 16 x 1" 2 ENGINE AND ATTACHING PARTS BHIGGS & STRATTON VÁNGUARD MODEL * (See your local engine dealer for other parts and repairs) 1 ENGINE - Briggs & Stratton Model 350447, type 0124 (18 hp) (1890V): 1 PLEEMER - air cleaner 1 BOLT - 5/16" - 18 x 1-1/4" 4 NUT - 5/16" - 18 x 1-1/4" 4 NUT - 5/16" - 18 x 1" 1 BOLT - 5/16" - 18 x 1" 1 DUCT - muffler, upper 1 DUCT - bottom 1 SUPPORT - duct front (use C45111) 3 CLAMP - exhaust			••••••••••		. .	· 1	
BOLT - 1/4" - 20 flange lock 7 CABLE - choke 1 CABLE - throttle 1 SCREW - #12 x 1/2" 4 NIPPLE - jipe 3/8" x 4" 1 LOCKWASHER 2/ BOLT - 3/8" - 16 x 1" 2/ ENGINE AND ATTACHING PARTS 2/ BRIGES & STRATTON VÁNCUARD MODEL 2/ ' (See your local engine dealer for other parts and repairs) 1 ENGINE - Briggs & Stratton Model 350447, type 0124 (18 hp) (1890V) : 1 ELEMENT - air cleaner 1 PRE-CLEANER 1 BOLT - 5/16" - 18 x 1-1/4". 4 NUT - 5/16" - 18 x 1-1/4". 4 NUT - 5/16" - 18 x 1-1/4". 4 DUCT - muffler, upper 1 DUCT - 5/16" - 18 x 1". 1 BOLT - 5/16" - 18 x 1". 1 BOLT - 5/16" - 18 x 1". 1 BOLT - 5/16" - 18 x 1". 1 DUCT - muffler, upper 1 DUCT - muffler, upper 1 DUCT - muffler, upper 1 DUCT - street elbow, 1/4" NPT 45° 1 NIPPEE - jipe 3.5". 1 PLUG	FILTER - air					1	· ·
CABLE - choke 1 CABLE - throttle 1 SCREW - #12 x 1/2" 4 NIPPLE - pipe 3/8" x 3-1/2" 4 NIPPLE - 3/8" x 4" 1 LOCKWASHER 2 BOLT - 3/8" - 16 x 1" 2 ENGINE AND ATTACHING PARTS 2 BRIGGS & STRATTON VANGUARD MODEL 2 ' (See your local engine dealer for other parts and repairs) 1 ENGINE - Briggs & Stratton Model 350447, type 0124 (18 hp) (1890V) : 1 ELEMENT - air cleaner 1 PRE-CLEANER 1 BOLT - 5/16" - 18 x 1-1/4" 4 NUT - 5/16" - 18 x 1-1/4" 4 NUT - 5/16" - 18 x 1-1/4" 4 NUT - 5/16" - 18 x 1'' 1 PIPE - exhaust 5 CLIP - 'J'' 1 PIPE - exhaust pipe 1 BOLT - 5/16" - 18 x 1" 1 DUCT - bottom 1 SUPPORT - duct front (use C45111) 1 SCREW - M6 x 10 2 CLAMP - exhaust 1 INPPLE - pipe 3.5" 1 NUPOR - duct front (use C45111) 2						· 7	
SCREW - #12 x 1/2" 4 NIPPLE - pipe 3/8" x 3-1/2". UAR NIPPLE - 3/8" x 4" 1 LOCKWASHER 2 BOLT - 3/8" - 16 x 1" 2 ENGINE AND ATTACHING PARTS 2 BRIGGS & STRATTON VANGUARD MODEL 2 (See your local engine dealer for other parts and repairs) 1 ENGINE - Briggs & Straton Model 350447, type 0124 (18 hp) (1890V) : 1 ELEMENT - air cleaner 1 PRE-CLEANER 1 BOLT - 5/16" - 18 x 1-1/4". 4 NUT - 5/16"A - 18 flange lock 5 CLIP - "J" 2 PIPE - exhaust 1 BRACKET - exhaust pipe 1 BOLT - 5/16" - 18 x 1" 1 DUCT - muiffler, upper 1 DUCT - muiffler, upper 1 DUCT - bottom 3 SUPPORT - duct front (use C45111) 3 SCLAMP - exhaust 2 FITTING - street elbow, 1/4" NPT 45° 1 NIT - oil sending 1 SHAET - stub 1 LOCKWASHER - 3/8" 2 PULLEY - engine (use 83-55 set screw)?<	CABLE - choke					, 1	
NIPPLE - pige 3/8" × 3-1/2". UAR NIPPLE - 3/8" × 4". 1 LOCKWASHER. 2 BOLT - 3/8" - 16 x 1". 2 ENGINE AND ATTACHING PARTS 2 BOLT - 3/8". 2 ENGINE AND ATTACHING PARTS 2 BOLT - 3/8". 2 ENGINE AND ATTACHING PARTS 2 BOLT - 3/8". 2 ENGINE - Briggs & Stratton Model 350447, type 0124 (18 hp) (1890V) 1 ELEMENT - air cleanet 1 PRE-CLEANER 1 BOLT - 5/16". 18 x 1-1/4". NUT - 5/16". 18 x 10. DUCT - bottom 2 PIPE - exhaust pipe 1 BOLT - 5/16". 18 x 1". DUCT - bottom 1 SUPPORT - duct front (use C45111). 1 SUPPORT - duct rear (use C45111). 1 SUPPORT - stub. 1 LOCKWASHER - 3/8" 2 NIT - 0il sending. 1	$CABLE - throttle \dots \dots$	· · · · · · · · · · · · · · · · · · ·	•••••			1	,
NIPPLE - 3/8" × 4" 1 LOCKWASHER 2 BOLT - 3/8" - 16 x 1" 2 ENGINE AND ATTACHING PARTS 2 BRIGGS & STRATTON VANGUARD MODEL 2 (See your local engine dealer for other parts and repairs) 1 ENGINE - Briggs & Stratton Model 350447, type 0124 (18 hp) (1890V) : 1 ELEMENT - air cleaner 1 PRE-CLEANER 1 BOLT - 5/16" - 18 x 1-1/4" 4 NUT - 5/16" - 18 x 1" 4 NUT - 5/16" - 18 x 1" 1 BOLT - 5/16" - 18 x 1" 2 PIPE - exhaust pipe 1 BOLT - 5/16" - 18 x 1" 1 DUCT - muffler, upper 1 DUCT - muffler, upper 1 DUCT - bottom 1 SUPPORT - duct front (use C45111) 1 SUPPORT - duct rear (use C45111) 3 CLAMP - exhaust 2 FITTING - street elbow, 1/4" NPT 45° 1 NIPPLE - pipe 3.5" 1 PULGEY - engine (use 83-55 set screw) 1 LOCKWASHER - 3/8" 2 BOLT - 3/8" - 16 x 1" 1 LOC	NIPPLE - pipe 3/8" x 3-1/2".					UAR	C123
BOLT - 3/8" - 16 x 1" 2 ENGINE AND ATTACHING PARTS BRIGGS & STRATTON VANGUARD MODEL (See your local engine dealer for other parts and repairs) ENGINE - Briggs & Stratton Model 350447, type 0124 (18 hp) (1890V) : ELEMENT - air cleaner 1 PRE-CLEANER 1 BOLT - 5/16" - 18 x 1-1/4" 4 NUT - 5/16" - 18 x 1-1/4" 4 BOLT - 5/16" - 18 x 1'' 1 PIPE - exhaust pipe 1 BOLT - 5/16" - 18 x 1" 1 DUCT - muffler, upper 1 DUCT - muffler, upper 1 DUCT - bottom 1 SUPPORT - duct front (use C45111) 1 SUPPORT - duct rear (use C45111) 1 SUPPORT - duct rear (use C45111) 3 CLAMP - exhaust 1 INPPLE - pipe 3.5" 1 PLUG - 1/2" - 20 1 UNT - oil sending 1 SHAFT - stub 1 LOCKWASHER - 3/8" 2 BOLT - 3/8" - 16 x 1" 2 PULLEY - engine (use 83-55 set screw)? 1 KEY - 1/4" x 1/4" x 1" 1 FITTINE - cill 1 CABLE - chroke	NIPPLE - 3/8'' x 4''					1	- ' T
ENGINE AND ATTACHING PARTS BRIGGS & STRATTON VANGUARD MODEL (See your local engine dealer for other parts and repairs) ENGINE - Briggs & Stratton Model 350447, type 0124 (18 hp) (1890V) : ENGINE - Briggs & Stratton Model 350447, type 0124 (18 hp) (1890V) : PRE-CLEANER BOLT - 5/16" - 18 x 1-1/4" NUT - 5/16" - 18 tange lock CLIP - "J" PIPE - exhaust pipe BOLT - 5/16" - 18 x 1" DUCT - muffler, upper DUCT - bottom SCREW - M6 x 10 CLAMP - exhaust SCREW - M6 x 10 CLAMP - exhaust PULG - 1/2" - 20 Ill DOCT - 3/8" - 6 x 1" DUCT - 3/8" - 6 x 1" DUCT - 12 x 1/4" x 1" ILLEMER - 3/8" DUCT - 12 x 1/4" x 1" BOLT - 3/8" - 6 x 1" DUCT - 12 x 1/4" x 1" ILLE - 12 x 1/4" x 1" ILLE - 14 x 1/4" x 1" ILLE - 14 x 1/4" x 1" ILLE -						2	
BRIGGS & STRATTON VANGUARD MODEL (See your local engine dealer for other parts and repairs) ENGINE - Briggs & Stratton Model 350447, type 0124 (18 hp) (1890V) : 1 PRE-CLEANER BOLT - 5/16" - 18 x 1-1/4" Your Sold (18 hp) (1890V) : 1 PRE-CLEANER BOLT - 5/16" - 18 x 1-1/4" Your Sold (18 hp) (1890V) : 1 PRE-CLEANER BOLT - 5/16" - 18 x 1-1/4" 4 NUT - 5/16" - 18 x 1-1/4" 9 BOLT - 5/16" - 18 x 1" 1 BOLT - shaust pipe 1 BOLT - 5/16" - 18 x 1" 1 DUCT - muffler, upper 1 DUCT - bottom 1 SUPPORT - duct front (use C45111) SUPPORT - duct front (use C45111) SCREW - M6 x 10 CLAMP - exhaust 1 PLUG - 1/2" - 20 UNIT - oil sending 1 SHPPLE - pipe 3.5" 1 NDREL - 1/2" - 16 x 1" 2 PULLEY - engine (use 8				· · · · · · · ·	, , , , , , , , , , , , , , , , , , , ,		
PRE-CLEANER 1 BOLT - 5/16'' - 18 x 1-1/4''. 4 NUT - 5/16'A - 18 flange lock 5 CLIP - ''J''. 2 PIPE - exhaust 1 BRACKET - exhaust pipe 1 BOLT - 5/16'' - 18 x 1''. 1 DUCT - muifler, upper 1 DUCT - muifler, upper 1 DUCT - bottom 1 SUPPORT - duct front (use C45111). 1 SUPPORT - duct rear (use C45111). 1 SCREW - M6 x 10 3 CLAMP - exhaust 2 FITTING - street elbow, 1/4'' NPT 45° 1 NIPPLE - pipe 3.5''. 1 PLUG - 1/2'' - 20 1 UNIT - oil sending 1 SHAFT - stub 1 LOCKWASHER - 3/8'' 2 PULLEY - engine (use 83-55 set screw)''. 1 KEY - 1/4'' x 1''. 1 FILTER - oil 1 CABLE - throttle 1 SCREW - #12 x 1/2''. 4	ENGINE - Briggs & Stratton M	lodel 350447, ty	ype 0124 (1	i8 hp) (1)	890V) :	1	2
BOLT - 5/16'' - 18 x 1-1/4''. 4 NUT - 5/16'' - 18 flange lock 5 CLIP - ''J'' 2 PIPE - exhaust 1 BRACKET - exhaust pipe 1 BOLT - 5/16'' - 18 x 1''. 1 DUCT - muffler, upper 1 DUCT - bottom 1 SUPPORT - duct front (use C45111) 1 SUPPORT - duct rear (use C45111) 1 SCREW - M6 x 10 3 CLAMP - exhaust 2 FITTING - street elbow, 1/4" NPT 45° 1 NIPPLE - pipe 3.5'' 1 PUG - 1/2" - 20 1 UNIT - oil sending 1 SHAFT - stub 1 LOCKWASHER - 3/8" 2 PULLEY - engine (use 83-55 set screw)" 1 KEY - 1/4" x 1/4" x 1" 1 FILTER - oil 1 CABLE - throttle 1 SCREW - #12 x 1/2" 4	PRE-CLEANER		••,•••••	• • • • • • • •			
CLIP - "J" 2 PIPE - exhaust 1 BRACKET - exhaust pipe 1 BOLT - 5/16" - 18 x 1" 1 DUCT - muffler, upper 1 DUCT - bottom 1 SUPPORT - duct front (use C45111) 1 SUPPORT - duct rear (use C45111) 1 SUPPORT - duct rear (use C45111) 1 SCREW - M6 x 10 3 CLAMP - exhaust 2 FITTING - street elbow, 1/4" NPT 45° 1 NIPPLE - pipe 3.5" 1 PLUG - 1/2" - 20 1 UNIT - oil sending 1 SCKWASHER - 3/8" 2 BOLT - 3/8" - 16 x 1" 2 PULLEY - engine (use 83-55 set screw)" 1 KEY - 1/4" x 1/4" x 1" 1 FILTER - oil 1 CABLE - throttle 1 SCREW - #12 x 1/2" 4 HARNESS - wire 1	BOLT - 5/16" - 18 x 1-1/4".					4	
PIPE - exhaust 1 BRACKET - exhaust pipe 1 BOLT - 5/16'' - 18 x 1'' 1 DUCT - múffler, upper 1 DUCT - bottom 1 SUPPORT - duct front (use C45111) 1 SUPPORT - duct rear (use C45111) 1 SCREW - M6 x 10 3 CLAMP - exhaust 2 FITTING - street elbow, 1/4'' NPT 45° 1 NIPPLE - pipe 3.5'' 1 PLUG - 1/2'' - 20 1 UNIT - oil sending 1 SHAFT - stub 1 LOCKWASHER - 3/8'' 2 PULLEY - engine (use 83-55 set screw)'' 1 KEY - 1/4'' x 1/4'' x 1'' 1 FILTER - oil 1 CABLE - choke 1 CABLE - choke 1 CABLE - throttle 1 SCREW - #12 x 1/2'' 4	NUT - 5/16" - 18 flange lock		• • • • • • • • •	• • • • • • • •			•
BOLT - 5/16" - 18 x 1" 1 DUCT - muffler, upper 1 DUCT - bottom 1 SUPPORT - duct front (use C45111) 1 SUPPORT - duct rear (use C45111) 1 SCREW - M6 x 10 3 CLAMP - exhaust 2 FITTING - street elbow, 1/4" NPT 45° 1 NIPPLE - pipe 3.5" 1 PLUG - 1/2" - 20 1 UNIT - oil sending 1 SHAFT - stub 1 LOCKWASHER - 3/8" 2 BOLT - 3/8" - 16 x 1" 2 PULLEY - engine (use 83-55 set screw)" 1 KEY - 1/4" x 1/4" x 1" 1 FILTER - oil 1 CABLE - throttle 1 SCREW - #12 x 1/2" 4 HARNESS - wire 1						1	
DUCT - muiffler, upper 1 DUCT - bottom 1 SUPPORT - duct front (use C45111) 1 SUPPORT - duct rear (use C45111) 1 SCREW - M6 x 10 3 CLAMP - exhaust 2 FITTING - street elbow, 1/4" NPT 45° 1 NIPPLE - pipe 3.5" 1 PLUG - 1/2" - 20 1 UNIT - oil sending 1 SHAFT - stub 1 LOCKWASHER - 3/8" 2 PULLEY - engine (use 83-55 set screw)? 1 KEY - 1/4" x 1/4" x 1" 1 FILTER - oil 1 CABLE - choke 1 CABLE - throttle 1 SCREW - #12 x 1/2" 4	BRACKET - exhaust pipe	••••••	•••••		· · · · · · · · `	1	•
DUCT - bottom 1 SUPPORT - duct front (use C45111) 1 SUPPORT - duct rear (use C45111) 1 SCREW - M6 x 10 3 CLAMP - exhaust 2 FITTING - street elbow, 1/4" NPT 45° 1 NIPPLE - pipe 3.5" 1 PLUG - 1/2" - 20 1 UNIT - oil sending 1 SHAFT - stub 1 LOCKWASHER - 3/8" 2 BOLT - 3/8" - 16 x 1" 2 PULLEY - engine (use 83-55 set screw) 1 KEY - 1/4" x 1/4" x 1" 1 FILTER - oil 1 CABLE - choke 1 CABLE - throttle 1 SCREW - #12 x 1/2" 4	BULT - 5/16 - 18 X I	· · · · · · · · · · · · · · · · · · ·	· · · · · · · · · · ·		· · · · · · ·	1	••
SUPPORT - duct rear (use C45111) 1 SCREW - M6 x 10 3 CLAMP - exhaust 2 FITTING - street elbow, 1/4" NPT 45° 1 NIPPLE - pipe 3.5" 1 PLUG - 1/2" - 20 1 UNIT - oil sending 1 SHAFT - stub 1 LOCKWASHER - 3/8" 2 BOLT - 3/8" - 16 x 1" 2 PULLEY - engine (use 83-55 set screw) 1 KEY - 1/4" x 1/4" x 1" 1 FILTER - oil 1 CABLE - choke 1 CABLE - throttle 1 SCREW - #12 x 1/2" 4	DUCT - bottom			•		1	· _ ·
SCREW - M6 x 10 3 CLAMP - exhaust 2 FITTING - street elbow, $1/4''$ NPT 45° 1 NIPPLE - pipe $3.5''$ 1 PLUG - $1/2'' - 20$ 1 UNIT - oil sending 1 SHAFT - stub 1 LOCKWASHER - $3/8''$ 2 BOLT - $3/8'' - 16 \times 1''$ 2 PULLEY - engine (use 83-55 set screw) 1 KEY - $1/4'' \times 1/4'' \times 1''$ 1 FILTER - oil 1 CABLE - choke 1 CABLE - throttle 1 SCREW - #12 x $1/2''$ 4 HARNESS - wire 1	SUPPORT - duct front (use C4 SUPPORT - duct rear (use C4	45111) 5111)	• • • • • • • •			1	~
NIPPLE - pipe 3.5" 1 PLUG - 1/2" - 20 1 UNIT - oil sending 1 SHAFT - stub 1 LOCKWASHER - 3/8" 2 BOLT - 3/8" - 16 x 1" 2 PULLEY - engine (use 83-55 set screw) 1 KEY - 1/4" x 1/4" x 1" 1 FILTER - oil 1 CABLE - choke 1 CABLE - throttle 1 SCREW - #12 x 1/2" 4 HARNESS - wire 1	SCREW - M6 x 10					3	
NIPPLE - pipe 3.5" 1 PLUG - 1/2" - 20 1 UNIT - oil sending 1 SHAFT - stub 1 LOCKWASHER - 3/8" 2 BOLT - 3/8" - 16 x 1" 2 PULLEY - engine (use 83-55 set screw) 1 KEY - 1/4" x 1/4" x 1" 1 FILTER - oil 1 CABLE - choke 1 CABLE - throttle 1 SCREW - #12 x 1/2" 4 HARNESS - wire 1	CLAMP - exhaust	NPT 45°	• • • • • • • •	•••••	• • • • • • •	2.	
PLUG - 1/2'' - 20 1 UNIT - oil sending 1 SHAFT - stub 1 LOCKWASHER - 3/8'' 2 BOLT - 3/8'' - 16 x 1'' 2 PULLEY - engine (use 83-55 set screw) 1 KEY - 1/4'' x 1/4'' x 1'' 1 FILTER - oil 1 CABLE - choke 1 SCREW - #12 x 1/2'' 4 HARNESS - wire 1	NIPPLE - pipe 3.5"	····	· · · · · · · · · · ·	. 	••• • • • • •	, i '	3
SHAFT - stub 1 LOCKWASHER - 3/8" 2 BOLT - 3/8" - 16 x 1" 2 PULLEY - engine (use 83-55 set screw) 1 KEY - 1/4" x 1/4" x 1" 1 FILTER - oil 1 CABLE - choke 1 CABLE - throttle 1 SCREW - #12 x 1/2" 4 HARNESS - wire 1						. 1	
LOCKWASHER - 3/8" 2 BOLT - 3/8" - 16 x 1" 2 PULLEY - engine (use 83-55 set screw) 1 KEY - 1/4" x 1/4" x 1" 1 FILTER - oil 1 CABLE - choke 1 CABLE - throttle 1 SCREW - #12 x 1/2" 4 HARNESS - wire 1	SHAFT - stub					1	- ,
PULLEY - engine (use 83-55 set screw) 1 KEY - 1/4" x 1/4" x 1" 1 FILTER - oil 1 CABLE - choke 1 CABLE - throttle 1 SCREW - #12 x 1/2" 4 HARNESS - wire 1	LOCKWASHER - 3/8"				• • • • • •	2	•
KEY - 1/4" x 1/4" x 1" 1 FILTER - oil 1 CABLE - choke 1 CABLE - throttle 1 SCREW - #12 x 1/2" 4 HARNESS - wire 1	BOLT - 3/8" - 16 x 1" PULLEY - engine (use 83-55 s	set screw)		• • • • • • •		2	
CABLE - choke 1 CABLE - throttle 1 SCREW - #12 x 1/2'' 4 HARNESS - wire 1	KEY - 1/4" x 1/4" x 1"					1	
CABLE - throttle 1 SCREW - #12 x 1/2" 4 HARNESS - wire 1	FILTER - oil	·············	•••••		•••••	1,	- ,
SCREW - #12 x 1/2"	CABLE - throttle		•			·1	
	SCREW - #12 x 1/2"	· 				. 4	
6		•••••••••	• • • • • • • • • •	• • • • • • • •		1	, ,
	í.				······································	, •	r
	<u>ل</u>	J .			· · ·	-	
	•		· •	·			æ

DECODIDITION					·
DESCRIPTION	•	•		REQ	D T
ENGINE - Briggs and Stratt	on, model 42244	17, Spec. No.	1277		`
(18 hp) (1800SS, 1890)				1	
DUCT - air	•••••••••••••••••	• • • • • • • • • • • •		1 UA	R 4
BOLT - 5/16" - 18 x 1-1/4	** *			4	••
NUT - 5/16'' - 18				4	- '
PLUG - pipe 3/8" PLUG - pipe 1/2" - 20	• • • • • • • • • • • • •	• • • • • • • • • • •		UA	· · · ·
SHAFT - stub			r .	1	" (`
KEY 1/4" x 1/4" x 1"					<u>``</u> .
PULLEY - drive (use 83-55 RETAINER - starter cable .					" t
ELBOW - street 1/8"			· · · · · · · · · · · ·	1	
UNIT - oil`sending				1	- 2
HÁRNESS - wire		• • • • • • • • • • •		1	
FILTER - air				1	
FILTER - oil				1	
BOLT - 1/4" - 20 flange lo	СК	•••••		1 1	
CABLE - throttle				1	•
ŚCREW - #12 x 1/2''				4	n Š
NIPPLE - pipe 3/8" x 3-1/2 NIPPLE - 3/8" x 4"	• • • • • • • • • • • • •	• • • • • • • • • • •		UA	м -' т
LOCKWASHER				2	1.
BOLT - 3/8'' - 16 x 1''	••••••••••		<i></i>	2	•
			•		
	TTACHING P			•	
BRIGGS & STRATT	•		_	•	
(See your local engine de) .		2 - 2
ELEMENT - air cleaner PRE-CLEANER BOLT - 5/16" - 18 x 1-1/4					
PIPE - exhaust BRACKET - exhaust pipe BOLT - 5/16" - 18 x 1" DUCT - muffler, upper DUCT - bottom SUPPORT - duct front (use SUPPORT - duct rear (use SCREW - M6 x 10 CLAMP - exhaust FITTING - street elbow, 1/ NIPPLE - pipe 3.5" PLUG - 1/2" - 20 UNIT - oil sending SHAFT - stub LOCKWASHER - 3/8" BOLT - 3/8" - 16 x 1" PULLEY - engine (use 83-5	,, c45111) c45111) 4″ NPT 45°			1 4 2 1	
CLIP - "J" PIPE - exhaust BRACKET - exhaust pipe BOLT - 5/16" - 18 x 1" DUCT - muffler, upper DUCT - bottom SUPPORT - duct front (use SUPPORT - duct rear (use SCREW - M6 x 10 CLAMP - exhaust FITTING - street elbow, 1/ NIPPLE - pipe 3.5" PLUG - 1/2" - 20 UNIT - oil sending SHAFT - stub LOCKWASHER - 3/8" BOLT - 3/8" - 16 x 1"	ock C45111) C45111) 4″ NPT 45° 55 set screw)			1 5 1	

DESCRIPTION	•	•		•	REQ'D	
ENGINE - Briggs and Stratton,	model 42244	17, Spec. No	. 1277		_	
(18 hp) (1800SS, 1890)	••••	· · · · · · · · · · ·	• • <i>• •</i> • • • •		1	
DUCT - air	م المتر	· · • · · · · · · · ·	••••• •		UAR	
BOLT - 5/16" - 18 x 1-1/4"	• • • • • • • • • • • •	• • • • • • • • • • •			4	
NUT - 5/16" - 18		· · · · · · · · · · · ·			4	,
PLUG = pipe 3/8"					UAR	
PLUG - pipe 1/2" - 20					UAR	Ϊ N
SHAFT - stub			······	••••	1	`.
PULLEY - drive (use 83-55 set	·····		• • • • • • •		1	-
RETAINER - starter cable					2	" 1
ELBOW - street 1/8"					1	
UNIT - oil'sending					1	
HARNESS - wire					. 1	
FILTER - air					1	-
					.1	`
BOLT - 1/4" - 20 flange lock				. \ . r	7	
CABLE - choke					1	
CABLE - throttle	,• • • • • • •				1	
SCREW - #12 x 1/2" NIPPLE - pipe 3/8" x 3-1/2".		••••••••			4	1.2.2
NIPPLE - pipe 3/8 × 3-1/2 . NIPPLE - 3/8'' × 4''	•••••	•••••		•.••••	UAR 1	
LOCKWASHER	· · · · · · · · · · · · · · · · · · ·		 		2	
BOLT - 3/8'' - 16 x 1''					Ź	
•		•	,	,		
	for other par	ts and repair		800\0		
(See your local engine dealer ENGINE - Briggs & Stratton M ELEMENT - air cleaner	for other par odel 350447	ts and repair , type 0124	(18 hp) (1		1	
(See your local engine dealer ENGINE - Briggs & Stratton M ELEMENT - air cleaner PRE-CLEANER	for other par	ts and repair	(18 hp) (1	· • • • • • • •	1 1 1 4	
(See your local engine dealer ENGINE - Briggs & Stratton M ELEMENT - air cleaner PRE-CLEANER BOLT - 5/16'' - 18 x 1-1/4'' NUT - 5/16' ^A - 18 flange lock	for other par odel 350447	ts and repair , type 0124	(18 hp) (1		1 1 1- 4 5	
(See your local engine dealer ENGINE - Briggs & Stratton M ELEMENT - air cleaner PRE-CLEANER BOLT - 5/16 ⁽¹⁾ - 18 x 1-1/4 ⁽¹⁾ NUT - 5/16 ⁽¹⁾ - 18 flange lock CLIP - ''J''	for other par	ts and repair , type 0124	(18 hp) (1		1 1 1 4 5 2	
(See your local engine dealer ENGINE - Briggs & Stratton M ELEMENT - air cleaner PRE-CLEANER BOLT - 5/16 ^(*) - 18 x 1-1/4 ^(*) NUT - 5/16 ^(*) - 18 flange lock CLIP - ^(*) J ^(*) - 18 flange lock CLIP - ^(*) J ^(*) - 18 flange lock	for other par	ts and repair , type 0124	(18 hp) (1		1 1 4 5 2 1	, , , , , , , , , ,
(See your local engine dealer ENGINE - Briggs & Stratton M ELEMENT - air cleaner PRE-CLEANER BOLT - 5/16'' - 18 x 1-1/4''' NUT - 5/16' ^A - 18 flange lock CLIP - ''J'' PIPE - exhaust BRACKET - exhaust pipe	for other par	ts and repair , type 0124	(18 hp) (1	· · · · · · · · · · · · · · · · · · ·	1 1 1 4 5 2 1 1 1	
(See your local engine dealer ENGINE - Briggs & Stratton M ELEMENT - air cleaner PRE-CLEANER BOLT - 5/16'' - 18 x 1-1/4'' NUT - 5/16'' - 18 flange lock CLIP - ''J'' PIPE - exhaust BRACKET - exhaust pipe BOLT - 5/16'' - 18 x 1''	for other par	ts and repair , type 0124	(18 hp) (1		1 1 4 5 2 1 1 1 1	
(See your local engine dealer ENGINE - Briggs & Stratton M ELEMENT - air cleaner PRE-CLEANER BOLT - 5/16'' - 18 x 1-1/4'' NUT - 5/16'' - 18 flange lock CLIP - ''J'' PIPE - exhaust BRACKET - exhaust pipe BOLT - 5/16'' - 18 x 1'' DUCT - muffler, upper DUCT - bottom	for other par	ts and repair , type 0124	(18 hp) (1		1 1 4 5 2 1 1 1 1 1	
(See your local engine dealer ENGINE - Briggs & Stratton M ELEMENT - air cleaner PRE-CLEANER BOLT - 5/16'' - 18 x 1-1/4'' NUT - 5/16'' - 18 flange lock CLIP - ''J'' PIPE - exhaust BRACKET - exhaust pipe BOLT - 5/16'' - 18 x 1'' DUCT - muffler, upper DUCT - bottom SUPPORT - duct front (use Co	for other par odel 350447	ts and repair , type 0124	(18 hp) (1		1 1 4 5 2 1 1 1 1 1 1	
(See your local engine dealer ENGINE - Briggs & Stratton M ELEMENT - air cleaner PRE-CLEANER BOLT - 5/16'' - 18 x 1-1/4''' NUT - 5/16'' - 18 flange lock CLIP - ''J'' PIPE - exhaust BRACKET - exhaust pipe BOLT - 5/16'' - 18 x 1'' DUCT - muffler, upper DUCT - bottom SUPPORT - duct front (use C4	for other par odel 350447,	ts and repair , type 0124	(18 hp) (1		1 1 4 5 2 1 1 1 1 1 2 1 1 1 1 2	
(See your local engine dealer ENGINE - Briggs & Stratton M ELEMENT - air cleaner PRE-CLEANER BOLT - 5/16'' - 18 x 1-1/4'' NUT - 5/16'' - 18 flange lock CLIP - ''J'' PIPE - exhaust BRACKET - exhaust pipe BOLT - 5/16'' - 18 x 1'' DUCT - muffler, upper DUCT - bottom SUPPORT - duct front (use C4 SUPPORT - duct rear (use C4 SCREW - M6 x 10	for other par odel 350447,	ts and repair , type 0124	(18 hp) (1		11145211111132	
(See your local engine dealer ENGINE - Briggs & Stratton M ELEMENT - air cleaner PRE-CLEANER BOLT - 5/16'' - 18 x 1-1/4'' NUT - 5/16'' - 18 flange lock CLIP - ''J'' PIPE - exhaust BRACKET - exhaust pipe BOLT - 5/16'' - 18 x 1'' DUCT - muffler, upper DUCT - bottom SUPPORT - duct front (use C4 SUPPORT - duct rear (use C4 SCREW - M6 x 10	for other par odel 350447,	ts and repair , type 0124	(18 hp) (1		1 1 4 5 2 1 1 1 1 1 3 2 1	
(See your local engine dealer ENGINE - Briggs & Stratton M ELEMENT - air cleaner PRE-CLEANER BOLT - 5/16'' - 18 x 1-1/4'' NUT - 5/16'' - 18 flange lock CLIP - ''J'' PIPE - exhaust BRACKET - exhaust pipe BOLT - 5/16'' - 18 x 1'' DUCT - muffler, upper DUCT - bottom SUPPORT - duct front (use C4 SCREW - M6 x 10 CLAMP - exhaust FITTING - street elbow, 1/4'' NIPPLE - pipe 3.5''	for other par odel 350447, 	ts and repair , type 0124	(18 hp) (1		2 1 1 1 1 1 3 2	
(See your local engine dealer ENGINE - Briggs & Stratton M ELEMENT - air cleaner PRE-CLEANER BOLT - 5/16'' - 18 x 1-1/4'' NUT - 5/16'' - 18 flange lock CLIP - ''J'' PIPE - exhaust BRACKET - exhaust pipe BOLT - 5/16'' - 18 x 1'' DUCT - muffler, upper DUCT - bottom SUPPORT - duct front (use C4 SCREW - M6 x 10 CLAMP - exhaust FITTING - street elbow, 1/4'' NIPPLE - pipe 3.5'' PLUG - 1/2'' - 20	for other par odel 350447, 	ts and repair	(18 hp) (1		2 1 1 1 1 1 3 2	
(See your local engine dealer ENGINE - Briggs & Stratton M ELEMENT - air cleaner PRE-CLEANER BOLT - 5/16'' - 18 x 1-1/4'' NUT - 5/16'' - 18 flange lock CLIP - ''J'' PIPE - exhaust BRACKET - exhaust pipe BOLT - 5/16'' - 18 x 1'' DUCT - muffler, upper DUCT - bottom SUPPORT - duct front (use C4 SCREW - M6 x 10 CLAMP - exhaust FITTING - street elbow, 1/4'' NIPPLE - pipe 3.5'' PLUG - 1/2'' - 20 UNIT - oil sending	for other par odel 350447, 45111) NPT 45°	ts and repair , type 0124	(18 hp) (1		2 1 1 1 1 1 3 2	· · · · · · · · · · · · · · · · · · ·
(See your local engine dealer ENGINE - Briggs & Stratton M ELEMENT - air cleaner PRE-CLEANER BOLT - 5/16'' - 18 x 1-1/4'' NUT - 5/16'' - 18 flange lock CLIP - ''J'' PIPE - exhaust BRACKET - exhaust pipe BOLT - 5/16'' - 18 x 1'' DUCT - múffler, upper DUCT - bottom SUPPORT - duct front (use C4 SUPPORT - duct rear (use C4 SCREW - M6 x 10 CLAMP - exhaust FITTING - street elbow, 1/4'' NIPPLE - pipe 3.5'' PLUG - 1/2'' - 20 UNIT - oil sending SHAFT - stub	for other par odel 350447, 	ts and repair , type 0124	(18 hp) (1		2 1 1 1 1 1 3 2	
(See your local engine dealer ENGINE - Briggs & Stratton M ELEMENT - air cleaner PRE-CLEANER BOLT - 5/16'' - 18 x 1-1/4'' NUT - 5/16'' - 18 flange lock CLIP - ''J'' PIPE - exhaust BRACKET - exhaust pipe BOLT - 5/16'' - 18 x 1'' DUCT - múffler, upper DUCT - bottom SUPPORT - duct front (use C4 SCREW - M6 x 10 CLAMP - exhaust FITTING - street elbow, 1/4'' NIPPLE - pipe 3.5'' PLUG - 1/2'' - 20 UNIT - oil sending SHAFT - stub LOCKWASHER - 3/8'' BOLT - 3/8'' - 16 x 1''	for other par odel 350447, 	ts and repair	(18 hp) (1		2 1 1 1 1 1 3 2	· · · · · · · · · · · · · · · · · · ·
(See your local engine dealer ENGINE - Briggs & Stratton M ELEMENT - air cleaner PRE-CLEANER BOLT - 5/16'' - 18 x 1-1/4'' NUT - 5/16'' - 18 flange lock CLIP - ''J'' PIPE - exhaust BRACKET - exhaust pipe BOLT - 5/16'' - 18 x 1'' DUCT - muffler, upper DUCT - muffler, upper DUCT - bottom SUPPORT - duct front (use C4 SCREW - M6 x 10 CLAMP - exhaust SCREW - M6 x 10 CLAMP - exhaust FITTING - street elbow, 1/4'' NIPPLE - pipe 3.5'' PLUG - 1/2'' - 20 UNIT - oil sending SHAFT - stub LOCKWASHER - 3/8'' BOLT - 3/8'' - 16 x 1'' PULLEY - engine (use 83-55 s	for other par odel 350447, 	ts and repair , type 0124	(18 hp) (1		2 1 1 1 1 1 3 2	
(See your local engine dealer ENGINE - Briggs & Stratton M ELEMENT - air cleaner PRE-CLEANER BOLT - 5/16'' - 18 x 1-1/4'' NUT - 5/16'' - 18 flange lock CLIP - ''J'' PIPE - exhaust BRACKET - exhaust pipe BOLT - 5/16'' - 18 x 1'' DUCT - muffler, upper DUCT - bottom SUPPORT - duct front (use C4 SCREW - M6 x 10 CLAMP - exhaust SCREW - M6 x 10 CLAMP - exhaust FITTING - street elbow, 1/4'' NIPPLE - pipe 3.5'' PLUG - 1/2'' - 20 UNIT - oil sending SHAFT - stub LOCKWASHER - 3/8'' BOLT - 3/8'' - 16 x 1'' PULLEY - engine (use 83-55 s KEY - 1/4'' x 1/4'' x 1''	for other par odel 350447, 45111) 5111) NPT 45° 	ts and repair , type 0124	(18 hp) (1		2 1 1 1 1 1 3 2	· · · · · · · · · · · · · · · · · · ·
(See your local engine dealer ENGINE - Briggs & Stratton M ELEMENT - air cleaner PRE-CLEANER BOLT - 5/16'' - 18 x 1-1/4'' NUT - 5/16'' - 18 x 1-1/4'' NUT - 5/16'' - 18 x 1-1/4'' PIPE - exhaust BRACKET - exhaust pipe BOLT - 5/16'' - 18 x 1'' DUCT - muffler, upper DUCT - bottom SUPPORT - duct front (use C4 SCREW - M6 x 10 CLAMP - exhaust SCREW - M6 x 10 CLAMP - exhaust FITTING - street elbow, 1/4'' NIPPLE - pipe 3.5'' PLUG - 1/2'' - 20 UNIT - oil sending SHAFT - stub LOCKWASHER - 3/8'' BOLT - 3/8'' - 16 x 1'' FILTER - oil	for other par odel 350447, 45111) 5111) NPT 45° set screw)	ts and repair type 0124	(18 hp) (1		2 1 1 1 1 1 3 2	
(See your local engine dealer ENGINE - Briggs & Stratton M ELEMENT - air cleaner PRE-CLEANER BOLT - 5/16'' - 18 x 1-1/4'' NUT - 5/16'' - 18 flange lock CLIP - ''J'' PIPE - exhaust BRACKET - exhaust pipe BOLT - 5/16'' - 18 x 1'' DUCT - muffler, upper DUCT - bottom SUPPORT - duct front (use C4 SCREW - M6 x 10 CLAMP - exhaust FITTING - street elbow, 1/4'' NIPPLE - pipe 3.5'' PLUG - 1/2'' - 20 UNIT - oil sending SHAFT - stub LOCKWASHER - 3/8'' BOLT - 3/8'' - 16 x 1'' FILTER - oil CABLE - choke	for other par odel 350447, 45111) 5111) NPT 45° 	ts and repair type 0124	(18 hp) (1		2 1 1 1 1 1 3 2	
(See your local engine dealer ENGINE - Briggs & Stratton M ELEMENT - air cleaner PRE-CLEANER BOLT - $5/16'' - 18 \times 1-1/4''$ NUT - $5/16'' - 18 \times 1-1/4''$ NUT - $5/16'' - 18 \times 1-1/4''$ PIPE - exhaust BRACKET - exhaust pipe BOLT - $5/16'' - 18 \times 1''$ DUCT - muffler, upper DUCT - bottom SUPPORT - duct front (use C4 SCREW - M6 × 10 CLAMP - exhaust FITTING - street elbow, $1/4''$ NIPPLE - pipe $3.5''$ PLUG - $1/2'' - 20$ UNIT - oil sending SHAFT - stub LOCKWASHER - $3/8''$ BOLT - $3/8'' - 16 \times 1''$ FILTER - oil CABLE - choke CABLE - thorttle	for other par lodel 350447, 45111) 5111) NPT 45°	ts and repair type 0124	(18 hp) (1		2 1 1 1 1 1 3 2	· · · · · · · · · · · · · · · · · · ·
(See your local engine dealer ENGINE - Briggs & Stratton M ELEMENT - air cleaner PRE-CLEANER BOLT - $5/16'' - 18 \times 1-1/4''$ NUT - $5/16'' - 18 \times 1-1/4''$ PIPE - exhaust BRACKET - exhaust pipe BOLT - $5/16'' - 18 \times 1''$ DUCT - muffler, upper DUCT - bottom SUPPORT - duct front (use C4 SCREW - M6 x 10 CLAMP - exhaust FITTING - street elbow, $1/4''$ NIPPLE - pipe $3.5''$ PLUG - $1/2'' - 20$ UNIT - oil sending SHAFT - stub LOCKWASHER - $3/8''$ BOLT - $3/8'' - 16 \times 1''$ PULLEY - engine (use $83-55 \times$ KEY - $1/4'' \times 1/4'' \times 1''$ FILTER - oil CABLE - choke CABLE - throttle SCREW - $#12 \times 1/2''$	for other par odel 350447, 45111) 5111) NPT 45° set screw)	ts and repair type 0124	(18 hp) (1		2 1 1 1 1 1 3 2	
(See your local engine dealer ENGINE - Briggs & Stratton M ELEMENT - air cleaner PRE-CLEANER BOLT - $5/16'' - 18 \times 1-1/4''$ NUT - $5/16'' - 18 \times 1-1/4''$ PIPE - exhaust BRACKET - exhaust pipe BOLT - $5/16'' - 18 \times 1''$ DUCT - muffler, upper DUCT - bottom SUPPORT - duct front (use C4 SCREW - M6 x 10 CLAMP - exhaust FITTING - street elbow, $1/4''$ NIPPLE - pipe $3.5''$ PLUG - $1/2'' - 20$ UNIT - oil sending SHAFT - stub LOCKWASHER - $3/8''$ BOLT - $3/8'' - 16 \times 1''$ FILTER - oil CABLE - choke CABLE - throttle SCREW - $#12 \times 1/2''$	for other par odel 350447, 45111) 5111) NPT 45° set screw)	ts and repair type 0124	(18 hp) (1		2 1 1 1 1 1 3 2	
(See your local engine dealer ENGINE - Briggs & Stratton M ELEMENT - air cleaner PRE-CLEANER BOLT - 5/16'' - 18 x 1-1/4'' NUT - 5/16'' - 18 flange lock CLIP - ''J'' PIPE - exhaust BRACKET - exhaust pipe BOLT - 5/16'' - 18 x 1'' DUCT - muffler, upper DUCT - bottom SUPPORT - duct front (use C4 SCREW - M6 x 10 CLAMP - exhaust FITTING - street elbow, 1/4'' NIPPLE - pipe 3.5'' PLUG - 1/2'' - 20 UNIT - oil sending SHAFT - stub LOCKWASHER - 3/8'' BOLT - 3/8'' - 16 x 1'' FILTER - oil CABLE - choke CABLE - throttle SCREW - #12 x 1/2'' HARNESS - wire	for other par odel 350447, 45111) 5111) NPT 45° set screw)	ts and repair type 0124	(18 hp) (1		2 1 1 1 1 1 3 2	
(See your local engine dealer ENGINE - Briggs & Stratton M ELEMENT - air cleaner PRE-CLEANER BOLT - 5/16'' - 18 x 1-1/4'' NUT - 5/16'' - 18 flange lock CLIP - ''J'' PIPE - exhaust BRACKET - exhaust pipe BOLT - 5/16'' - 18 x 1'' DUCT - muffler, upper DUCT - bottom SUPPORT - duct front (use C4 SCREW - M6 x 10 CLAMP - exhaust FITTING - street elbow, 1/4'' NIPPLE - pipe 3.5'' PLUG - 1/2'' - 20 UNIT - oil sending SHAFT - stub LOCKWASHER - 3/8'' BOLT - 3/8'' - 16 x 1'' FILTER - oil CABLE - choke CABLE - throttle SCREW - #12 x 1/2'' HARNESS - wire	for other par odel 350447, 45111) 5111) NPT 45° set screw)	ts and repair type 0124	(18 hp) (1		2 1 1 1 1 1 3 2	
(See your local engine dealer ENGINE - Briggs & Stratton M ELEMENT - air cleaner PRE-CLEANER BOLT - $5/16'' - 18 \times 1-1/4''$ NUT - $5/16'' - 18 \times 1-1/4''$ PIPE - exhaust BRACKET - exhaust pipe BOLT - $5/16'' - 18 \times 1''$ DUCT - muffler, upper DUCT - bottom SUPPORT - duct front (use C4 SCREW - M6 x 10 CLAMP - exhaust FITTING - street elbow, $1/4''$ NIPPLE - pipe $3.5''$ PLUG - $1/2'' - 20$ UNIT - oil sending SHAFT - stub LOCKWASHER - $3/8''$ BOLT - $3/8'' - 16 \times 1''$ FILTER - oil CABLE - choke CABLE - throttle SCREW - $#12 \times 1/2''$ HARNESS - wire	for other par odel 350447, 45111) 5111) NPT 45° set screw)	ts and repair type 0124	(18 hp) (1		2 1 1 1 1 1 3 2	


ELECTRIC CLUTCH (PTO)

REF.

a		
PART NO.	DESCRIPTION	REQ'D
C 37511 C 37569 C 37549 C 37550 C 37570 C 37551 C 37552 C 37552 C 37553 C 37562 C 37562 C 31615 C 37981 192- 21 C 31614 192- 22 113- 335 114- 203 C 37562	CLUTCH ASSEMBLY (1800SS, 1800KSS, 1890, 1890K, 1890V) CLUTCH ASSEMBLY (2000) BRAKE - clutch ARMATURE - clutch (1800SS, 1800KSS, 1890, 1890V) ARMATURE - clutch (2000) ROTOR - clutch KIT - spring and nut (3 each) COIL - clutch BRACKET - clutch stop (current production) WASHER - retaining WASHER - 1'' (early production) LOCKWASHER - 3/8'' WASHER - 1-1/8'' LOCKWASHER - 7/16'' - 14 x 3/4'' BOLT - 3/8'' - 24 x 1-1/2'' BRACKET - clutch stop (early production)	1 1 1 1 2 2
•	FUEL SYSTEM	1
•		. •
C 37554 C 44027 214- 103 NSS C 45119 C 44290 C 44822 C 45334 C 37812 C 37811 131- 934 113- 1 113- 3 C 32455 C 45333 NSS C 45061 C 45062 113- 5 131- 71 113- 103 131- 911 C 34189	FILTER - fuel HOSE - fuel (cut to length) CLAMP - hose TANK - fuel (1- $3/4''$ filler tube) (use C45119, C44822) metal TANK fuel (2- $1/4''$ filler tube) metal CAP - fuel tank (with gauge) (1- $3/4''$ threads) CAP - fuel tank (with gauge) (2- $1/4''$ threads) use on metal tank. CAP - fuel tank (with gauge) (2- $1/4''$ threads) (use on plastic tank) NIPPLE - pipe 1/8'* VALVE - shut off NUT - $1/4'' - 20$ x $1/2''$ BOLT - $1/4'' - 20$ x $3/4''$ CLIP - $''J''$ fuel line TANK - fuel (2- $1/4''$ filler tube) (plastic) TANK - fuel (2- $1/4''$ filler tube) (plastic) (use C45333, C45334) BRACKET - fuel tank STRAP - fuel tank BOLT - $1/4'' - 20$ x $1-1/2''$ NUT - $1/4'' - 20$ lock BOLT - $5/16'' - 18$ flange lock CUSHION	1 1 1 4 1 3 1 1 1 1 1 2
•••		

(8)

Э.	DESCRIPTION	REQ'D
11	CLUTCH ASSEMBLY (1800SS, 1800KSS, 1890, 1890K, 1890V)	1
	CLUTCH ASSEMBLY (2000)	1
49	BRAKE - clutch	1
50 50	ARMATURE - clutch (1800SS, 1800KSS, 1890, 1890V)	1
70	ARMATURE - clutch (180033, 1800K33, 1890, 1890V)	· 1
-		1
51	ROTOR - clutch	1 *
52	KIT - spring and nut (3 each)	1
53.	COIL - clutch	1
62	BRACKET - clutch stop (current production)	1
15	WASHER - retaining	
81	WASHER - 1"/ (early production)	1
21	LOCKWASHER - 3/8"	1
14	WASHER - 1-1/8''	1
22	LOCKWASHER - 7/16''	2
3,5	BOLT - 7/16'' - 14 × 3/4''	2
03	BOLT - 7/16'' - 14 x 3/4'' BOLT - 3/8'' - 24 x 1-1/2''	1
62	BRACKET - clutch stop (early production)	2
		·
	FUEL SYSTEM	, ,
•		
54	FILTER - fuel	1
	FILTER - Tuel	. 1
27	HOSE - fuel (cut to length)	4
03	CLAMP - hose	4.
		1
19	TANK fuel (2-1/4" filler tube) metal	1
90	CAP - fuel tank (with gauge) (1-3/4" threads)	1 1
22	CAP - fuel tank (with gauge) (2-1/4" threads) use on metal tank	1
34	CAP - fuel tank (with gauge) (2-1/4" threads) (use on plastic tank)	1
12	NIPPLE - pipe 1/8'*	1 .
11	VALVE - shut off	1
34	NUT - 1/4" - 20 flange lock	4
1 ´	BOLT – 1/4'' - 20 x 1/2'' BOLT - 1/4'' - 20 x 3/4''	1
3	BOLT - 1/4'' - 20 x 3/4''	З
55	CLIP - "J" fuel line	1.
33	TANK - fuel (2-1/4" filler tube) (plastic)	1
	TANK - fue! (1-3/4" filler tube) (plastic) (use C45333, C45334)	1
61	BRACKET - fuel tank	<u>,</u> 1
62	STRAP - fuel tank	1
5	BOLT - 1/4'' - 20 x 1-1/2''	2
71	BOLT - 1/4'' - 20 x 1-1/2''	2
03	BOLT - 5/16'' - 18 x 1''	2
11	NUT - 5/16" - 18 flange lock	2
89	CUSHION	2
		•
,		
·		



0---11


(9)

(5)

(4)

(6)

(3)



1-


BASE ASSEMBLY

(1890, 1890K, 1890V)

	· · · · · · · · · · · · · · · · · · ·			
T NO.	DESCRIPTION	4 - 5		REQ'D
42892	BASE			1
37575	ARM - deck lift R.H. (1890, 1890K)			1
37574	ARM - front L.H (1890, 1890K)			1
37573	ARM - front R.H. (1890, 1890K)			1
37578	PIN erese bar		•••••	1
	PIN - cross bar			1
37579				1
37577	TUBE - wire			1
37583	LOCK - forward nose down		• • • • • • • • • • • • • • •	2
45390	/ TUBE - drive idler (1890, 1890K) .			. 1
44329	TUBE - drive idler (1890V)		**********	1
37576	BUSHING - deck lift arm (3/8" long)		3
37586	BUSHING - pivot (1/2" long)			1
- 417	BOLT - 1/2" - 13 x 1-1/4"			6
- '441 '	BOLT - 1/2" - 13 x 2-1/4"			, 1
37582	BOLT - 3/8'' - 16 x 3''		*	2
- 106	WASHER - 1/2''	,	•••••	8
- 23	LOCKWASHER - 1/2"		• • • • • • • • • •	0 7
- 104	WASHER - 3/8"			2
- 938	NUT - flange lock 3/8'' 16			2 1
- 105	NUT - 1/2" - 13			
- 310 -	PIN - cotter 1/8'' x 1''			2
37595	SPRING - idler tension			1
15672	PULLEY - idler 2-1/4" O.D		• • • • • • • • • •	· 1
37597	SCREW - machine #10 - 32 x 5/8':			2
37521	SWITCH - safety			1
37598	NUT - lock #10 - 32			2
38594	ARM - deck lift L.H. (1890, 1890K	<u>}</u>		1
- 7,1	NUT - lock 1/4" - 20			4
- 103	NUT - 3/8'' 16			5 '
2- 21	LOCKWASHER - 3/8"		*	1
- 257	BOLT - 3/8" - 16 x 2-1/2"	· · · · · · · · · · · · · · · · · · ·		1
37815	SPRING - lift assist	·		2
37816	CABLE - lift	•		2
· 4	BOLT - 1/4" - 20 x 1"			4
44249	ARM - deck-L.H. (shown) 1890V (u			. 1
44250	ARM - deck R.H. (1890V)			1
45099	ARM - deck L.H. 1890V (use PIN 9			1
44245	ARM - idler (1890V) (use before PI			. 1
45095	ARM - idler 1890V (use PIN 95340			1
25229	BEARING - flange (1890V)			2
25370	PULLEY - "V""idler (1890V)			1
45102	BUSHING - pulley (1890V)			1 '
12251	PULLEY - flat (1890V) shown (use	hoforo PIN 952401026	· · · · · · · · · · · · · · · · · · ·	1
45121	PULLEY - idler, flat (use PIN 95340			1
				2
)- 103	NUT - 3/8" - 16 (1890V)			
- 938	NUT - 3/8" - 16 flange lock			1
5- 104	WASHER - 3/8" (1890V)			UAR
2- 21	LOCKWASHER - 3/8" (1890V) (use			
3- 219	BOLT - 3/8" - 16 x 2" (1890V)			2
44242	SPRING - extension (1890V)	••••		1
3- 103	BOLT - 5/16" - 18 x 1" (1890V) .			1
- 911	NUT - 5/16" - 18 flange lock (189)			1
28263	WASHER - spring (1890V)			1 ′
- 1182	NUT - 1/2" - 13 lock 1890V (use I			· 1
5-533	WASHER - 1/2" 1890V (use PIN 9			1
41051	TUBE - spring loaded idler (included	I with base)		1
44405	GUARD - belt (1890V)			1
3- 102	BOLT - 5/16" - 18 x 3/4"			2
2- 20	LOCKWASHER			2
-				. '

(10)

		r ven			· .
in the second seco			BASE ASSEMBLY 1800SS, 1800KSS)		
	REF.	. PART NO.	DESCRIPTION	REQ	ם'ב
$\begin{array}{c} 2 \\ 0 \\ 0 \\ 0 \\ 0 \\ 0 \\ 0 \\ 0 \\ 0 \\ 0 \\$	1 2 2 3 4 5 7 8 9 10 11 12 13 14 15	C 37572 C 37573 C 37574 C 37575 C 37576 C 38990 C 38988 C 37586 C 37581 C 37581 C 37582 C 37583 C 37577 C 37579 C 37578 C 38651	BASE - (includes ref. 15) DECK LIFT ARM - Front RH (shown) DECK LIFT ARM - Front LH DECK LIFT ARM - Back BUSHING, Short BELT RETAINER BELT RETAINER BUSHING - Long WASHER DECK BELT ADJUSTMENT BOLT FORWARD NOSE DOWN LOCK WIRE TUBE CROSS BAR CROSS BAR PIN TUBE - spring loaded idler (is part of base)		1 1 2 2 1 2 1 2 1 1 1 1 1 1
	2	· .	BASE ASSEMBLY		•
34- $3-$ $34-$ $3-$ $3-$ $3-$ $3-$ $3-$ $3-$ $3-$ 3	$ \begin{array}{c} 1\\ 2\\ 3\\ 4\\ 5\\ 6\\ 7\\ 8\\ 9\\ 10\\ 11\\ 12\\ 13\\ 14\\ 15\\ 16\\ 17\\ 18\\ 19\\ 20\\ 21\\ 21\\ 15\\ 16\\ 17\\ 18\\ 19\\ 20\\ 21\\ 21\\ 22\\ 23\\ 24\\ 25\\ 26\\ 11\\ 27\\ 27\\ 28\\ 28\\ 29\\ 29\\ 30\\ 31\\ 32\\ 33\\ 34\\ 35\\ 35\\ 35\\ 35\\ 35\\ 35\\ 35\\ 35\\ 35\\ 35$	N/A C 37619 C 37620 NSS* C 37622* C 37623*	2000 BASE - (includes ref. 34) LIFT BAR CROSS BAR PIN. DECK LIFT ARM - Front Adjustable LH DECK LIFT ARM - Front Adjustable LH DECK LIFT ARM - Back RH. DECK LIFT ARM - Back LH (shown) BUSHING - Long WIRE TUBE BUSHING - short IDLER PULLEY SPRING LOADED IDLER MOUNT SPRING LEVER - brake BRAKE CLUTCH ROD BRAKE ROD CROSS ROD BEARING DECK ARM ADJUSTING BOLT GRIP - handle. BRAKE CABLES AXLE BRAKE CLIFT MOUNT CABLE END - (use C42895, C42896) BUSHING - (use C42895, C42896) BUSHING - (use C42895, C42896) CLAMP CABLE DEAD HEAD TIRE ASSEMBLY - 20 x 10.00-10 TIRE - 20 x 10.00-10 RIM TIRE ASSEMBLY - 20 x 10.00 - 10 RIM TIRE ASSEMBLY - 20 x 10.00 - 10 LUG BOLT - 7/16'' - 20 x 3/4'' LUG BOLT - 7/16'' - 20 x 3/4'' LUG BOLT - 7/16'' - 20 x 10.00 - 10 RIM TIRE ASSEMBLY - 20 x 10.00 - 10 RIM TIRE ASSEMBLY - 20 x 10.00 - 10 RIM TIRE ASSEMBLY - 20 x 10.00 - 10 LUG BOLT - 7/16'' - 20 x 3/4'' LUG BOLT - 1/2'' - 20 x 1'' BRAKE CALIPER - L.H. (Shown) BRAKE PUCKS HUB NUT.		1 1 1 1 1 1 2 2 1 2 1 2 1 2 1 2 1 2 1 2
11			(12)	• • •	



OK, 189	OV)		
.,	· · ·	ł	REO'D
		· · · · · · · · · · · · · ·	. 1,
· · · · · · ·	· · · · · · · · · · · ·		· 1 · 1 · 1
· · · · · · ·	· · · · · · · · · · · · · ·	• • • • • • • • • • • • • • • • • • •	· · · ·
•••••	••••	· · · · · · · · · · · · · · · · · · ·	. 2. . 1
•••••		· · · · · · · · · · · · · · · · · · ·	. 1
· · · · · · · ·			. 1 • . 1
-	· · · · · · · · · · · ·		. 1 . 8
		· · · · · · · · · · · · ·	. 8 . 4
••••••	· · · · · · · · · · ·	· · · · · · · · · · · · ·	. 4
 	· · · · · · · · · · · ·	•••••	. 4 . 2 . 2 ·
····· ····	Second Contractors And Contractors	د	1
 	· · · · · · · · · · · · · · · · · · ·	u ``	8 4 1
· · · · · · · ·		· · · · · · · · · · · · · · · · · · ·	4
	· · · · · · · · · · · · · · · · · · ·		. 1, . UAR
		· · · · · · · · · · · · · · · · · · ·	. 1
 	· · · · · · · · · · · · · · · · · · ·		· 1 · 4
<i>.</i>	· · <i>: : · · · · · · · · · · · · · · · ·</i>		- 4, . 4
• • • • • • • •			. 2 ·
•••••	· · · · · · · · · · · ·	· · · · · · · · · · · · ·	, 2 , 2
· · · · · · ·	···· 42		· · · · · · · · · · · · · · · · · · ·
	· · · · · · · · · ·	· · · · · · · · · · · · · · · · · · ·	· · · · · · · · · · · · · · · · · · ·
		· · · · · · · · · · · · · · · · · · ·	·· · ·
•	. "	.*	
	-		-
	. <i>.</i> •		
	а. - -	*,	- , *
			¥-
		· · ·	

BODY ASSEMBLY 2000

•		
REF.	PART NO.	DESCRIPTION
. 1	C 45498	BODY
2	C 41167	FENDER - L.H. (shown)
P -	C 41171	FENDER - R.H.
. 3	C 41187	BACK COVER
4	C 44844	GUARD RAIL
. 5	C37835	HOLD DOWN
6	C 37836	TOP CYLINDER MOUNT - before PIN 953
7.	C 37810	TAIL WEIGHT
·8	C 37821	DASHBOARD
9	C 41944	DZUS FASTENER
10	C ⁻ 37811	SHUTOFF VALVE
<u> </u>	C /37812	NIPPLE - 1/8''
12	NSS	FUEL TANK - 1-3/4" filler tube (use C45
12 ′	C 45119	TANK - fuel (2-1/4" filler tube)
្នា3	C 44290	FUEL TANK CAP w/Gauge - 1-3/4"
13	C 44822	CAP - fuel tank, with gauge (2-1/4" thre
14	C 37824	BEARING
15	C 37515	RELAY
16	C 37815	DECK SPRING
17 .	C 41010	BATTERY
18	. C 37506	LIGHT ASSEMBLY
19	C 22573	LENS
20	C 14304	GASKET
21	C 37508	BULB
. 22	C 37509	LAMP
24	C 38408	SPRING
25	C 43044	
26	C 31937	CLUTCH SWITCH
27	C .37519 C 37820	· OIL LIGHT
28 29		THROTTLE CABLE
30	C 24145 C 37518	HOUR METER
31	C 37518	AMP METER
32	C 37819	CHOKE CABLE
32	-C 37818	RUBBER BODY MOUNT
34	C 37581	BODY MOUNT WASHER
35	C 37958	TAIL WEIGHT - 13 lb. (optional)
35 37		PAD - safety, front LH
37	C 43419 C 43920	PAD - safety, front RH
38	C 43421	PAD - safety, side

12 0 15 9 14 60 10 33 -72

9--9

0.

(38)

-13

Ľ

15

REQ'D -1 ~ ************* · 1 3408001 only 5119, C44822).... 2 3 2 2 2 المرجع والمستعد والمتعاد والمتعال والمتعال والمتعال والمتعال والمتعال والمتعال والمتعال والمتعال والمتعال والم 2 2 . . 5 8 4. UAR 1 1 1

SEAT LID AND STEERING

PART NO 38054 4423 3784 3784 4289 3784 3784 3784 4491 4448 NSS

REF.

2 3

> 6 6

8 9 9

(14

(24

⊙'-

(44

(45)

(28)

42+83

(44) (24)

(43)

(25) (26)

(29)

(31)

(10)

 $\begin{array}{c} 10\\ 11\\ 12\\ 14\\ 15\\ 16\\ 17\\ 18\\ 99\\ 90\\ 20\\ 12\\ 23\\ 24\\ 25\\ 27\\ 28\\ 90\\ 31\\ 23\\ 34\\ 56\\ 37\\ 89\\ 41\\ 42\\ 44\\ 45\\ 46\\ 47\\ \end{array}$

48 49

(18)

(38)

(37)

(21)

40

(31)

1000

46

(34)

(19)

20)

(35)

(48)

ি

(26)

30

1)


(1)

	SEAT LID AND STEERING	
PART NO	DESCRIPTION	REQ'D
C 42895	LID - seat (1890, 1890K, 2000, 1800SS, 1800KSS) LID - seat (1890, 1890K, 1890V, 2000) BRACKET - lever lock LATCH - lever lock BUSHING - (also order C42896)	1 1 1 2
C 37842 C 37843* C 44915** C 44481 NSS	BEARING - block LEVER - steering (1890, 1890K, 2000, 1800SS, 1800KSS) LEVER - steering (1890, 1890K, 1890V, 2000) LATCH - seat lid BOLT latch, seat lid (is included with C44481)	4 2 1 1
C 37713 C 42896	BRACKET - steering cable end (2000) BRACKET - steering cable end (also order C42895) (1800SS, 1800KSS, 1890, 1890K, 1890V)	4
C 32455 C 44012 C 37847* C 43202**	RETAINER - harness, seat lid SWITCH - seat SEAT - (1890, 1890K, 2000, 1800SS, 1800KSS) SEAT - (1890, 1890K, 1890V, 2000)	. 1 · · ·
C 37850* C 37851 C 37837 C 37521	SPACER - seat	1 [,] 1
	GRIP - handle CABLE - steering (1890, , 1890K, 1890V) (see page 49) CABLE - steering (1800SS, 1800KSS) CABLE - steering (2000)	2 2 2 2
C 37616 C 37718 C 37852 C 37848*	CLAMP - steering cable (1800SS, 1800KSS, 1890, 1890K, 1890V) CLAMP - steering cable (2000) PROP - seat lid	1
C 37853 195- 103 131- 69 113- 4 105 102	SPRING - seat	4 4 2
195- 102 131- 71 113- 103 182- 528 193-1000	NUT - 1/4" - 20 lock BOLT - 5/16" - 18 x 1" SCREW - #10 - 32 x 1/2"	3 2 3 7 -
111- 114 195- 102 131- 71 113- 3 C 42359	BOLT - 1/4" - 20 x 1-1/2" carriage WASHER - 1/4" NUT - 1/4" - 20 lock BOLT - 1/4" - 20 x 3/4" BOLT 1/4" - 20 x 2"	10
113- 3 192- 19 182- 525 192- 18	BOLT - 1/4" - 20 x 3/4" LOCKWASHER - 1/4" SCREW - #10 - 32 x 3/8" LOCKWASHER - 3/16"	2 2 1 1
C 43137** C 43438** 111- 204 192- 20	SPRING - seat (1890, 1890K, 1890V, 2000)	2 4 4
113- 103 131-1102 NSS C 22947	LOCKWASHER - 5/16 [#] BOLT - 5/16 ["] - 18 x 1" NUT - 1/4 ["] - 20 KIT - arm rest (optional) (order as machinery item) TIE - nylon	
C 37826 C 44498 C 37830	PLATE - filler	1
	* Use before PIN: ** Use PIN and after: G2000C II - 953401031 G1890 - 953404001 G1890K - 953403006	
· · ·	G1890V - all after	· · · ·

, SINGLE TAIL WHEEL

(20)

			· · · · ·
	REF.	PART NO.	DESCRIPTION
	1 2 3 4 5 6 7 8 9 10	C 37854 C 37855 C 37856 C 37857 C 37858 C 37859 C 37860 C 37861 113- 452 85- 58 192- 23 129- 105 C 37824 219- 92	AXLE - wheel
fra da anti-	۰. ۲	* • •	
, , , , ,			DUAL TAIL WHE
	1 2 3 4	C 37863 C 39016 C 37865 C 37866	AXLE - dual wheel FORK - tail wheel BRACKET' - mounting TUBE - block
<i>ः</i>	5 6 7	C 38230 C 37915 C 37869 C 44499 C 37870	PIVOT - axle
- - 	8 9 10 11 12	C 37871 C 37824 C ∛37860 113-2419 192- 23 129- 105	RIM BEARING - 1" COLLAR - set 1" BOLT - 1/2" - 13 x 6-1/2" LOCKWASHER - 1/2" NUT - 1/2" - 13
	13	C 37756 219- 92	SCREW - set 5/16" - 18 x 1/2" squ FITTING - grease 90° 1/4" - 28 self
•	•		• • •



(19)

	-			
	-			REQ'D
				1
				1
£	,	• • • • • • • •	· · · · · · · · · · · ·	8.
· · · · · · · · ·				• 1
				1 '
				1
			· · · · · · · · · ·	1
lare head				1 '
				1
,		· · · · · · · · · ·	· • • • • • • • • • • •	2
				ĩ
			. •	•
e e i	· -			
EEL		,	,	•
	•			1
		· • · · · · · · · ·	· · · · · · <u>·</u> · · · ·	2
				. 1
		•		, 1
		 		1
			· · · · · · · · · · · · · · · · · · ·	2
.» 				2 2 2
				2
• • • • • • • • •	•••••	•••••••		2
			• • • • • • • • • • • • • •	、 6 4
			· · · · · , · · · · · ·	
				2 2
		• • • • • • • •	· · · · · · · · · · · · · · · · · · ·	· 2
luare nead If tap (ca	a stor.nivo	 the second	· · · · · · · · · · ·	4 UAR
	, , , , , , , , , , , , , , , , , , ,	.,		^b
		<i>k</i>	¥ *	
,	•.• ·	. '	-	a 52
	, , ,		i.	
	÷. F.			
			·	2
			,	
· .	• ,•		· · ·	2 °
•	٩	5. A -	ч Э	
· · ·		· · ·		•
	`	· ·		•
,			•	
17			,	· · ·
	,	•	,	
		-		
	•	.*		•
· .			•	· · · ·
	· · ·	•	,	,
			- ▲	
•				

PUMP	DRIVE
400000	40001/0/

		1800SS, 1800KS
	PART NO.	DESCRIPTION
	C 37694	HUB w/drive plate
	C 37695	PULLEY w/drive plate
	C 37696	CCW FAN
	C 37697	CW FAN
	C 37698	TRANSMISSION ARM L.H.
	C 37699	TRANSMISSION ARM - R.H
	C 37700	DRIVE PLATE
	C 37701	TRANSMISSION CROSS SHAFT
	C_37702	BOLT SPACER
	C 37703	SPACER
	C 37704	WASHER - 1/4" 10 ga
	C 37614	STEERING CABLE END
	C 37615	BUSHING - steering lever
-	C 37616	STEERING CABLE CLAMP
	C 37705	STEERING CABLE
	C. 38507	BELT RETAINER - Transmission
	C 37707	BELT
	0 0//0/	

REF.

9

Ì5

6

5

18

(7)

6)

				,
•			5	
	· · · · · · · · · · · · · · · · · · ·		-	
	PUMP DR	IVF	•	• •
	1800SS, 180		. *	
PART NO.	DESCRIPTION	UNGG		REQ'D
PART NO.	DESCRIPTION			heu v
C 37694	HUB w/drive plate	- `	···	1 🐇
C 37695	PULLEY w/drive plate			
C 37696	CCW FAN			
	CW FAN	•••••••••••	1 .	1 *
C 37697	TRANSMISSION ARM L.H.		• • • • • • • • • • • • • • • •	1 1 1 1 1 1
C 37698				
C 37699	TRANSMISSION ARM - R.H.			
C 37700	DRIVE PLATE	<u>.</u>		
C 37701	TRANSMISSION CROSS SHAFT			
C 37702	BOLT SPACER	,		4
- C 37703	SPACER			
C 37704	WASHER - 1/4" 10 ga			6 .
C 37614	WASHER - 1/4" 10 ga		· · · · · · · · · · · · · · · · · · ·	4
C 37615	BUSHING - steering lever		" "	4
	STEERING CABLE CLAMP			
C 37705	STEERING CABLE	• • • • • • • • • • • • •	•••••	
C. 38507	BELT RETAINER - Transmission .	[.]	•••••	
C 37707	BELT			1 ·
•				e
	•	•	• •	2 · · · · · · · · · · · · · · · · · · ·
4 ° * *	PUMP DR		e	
1	2000		• .	•
	, .			· · · · · · · · · · · · · · · · · · ·
0 07700	HUB - w/drive plate	· · · ·	~	ೆ.ಸ್ಕ್ರಿ ಲಿ.ಪ್ರೆ.ಗಳ ಕಾ
C 37708	HUB - w/drive plate		· · · · · · · · · · · · · · · · · · ·	
C 37700 、	DRIVE PLATE			
C 37703	SPACER			
C 37709	CROSS SHAFT			
C 37702	BOLT SPACER		• • • • • • • • • • • • •	
C 37710	CROSS BAR-BLOCK			1
C 38438	TRANSMISSION BELT RETAINER			
C 37711	TRANSMISSION ARM - L.H.			
C 37712	TRANSMISSION ARM - R.H			1
C 37713	STEERING CABLE ENDS			4.
C 42895	STEERING CABLE ENDS BUSHIN	IG		
C 37696	CCW FAN - L.H			
C 37697	CW FAN - R.H.			1 ·
C 37704	WASHER - 5/16"			
C 37715	PULLEY			
C 37716	BELTS			
C 37717	STEERING CABLE			
C 37718	CLAMP			
	KEY - woodruff			
126-11	CLAMP - cable (at fan)			
C 33125				
113- 102.	BOLT - 5/16'' - 18 x 3/4''			1
195-`` 103	WASHER - 5/16"			
131- 911	NUT - 5/16" - 18 flange lock			
126- 16	KEY - 3/16" x 3/4" woodruff.	••••	· · <u>·</u> · · · · · · · · · · · · · · ·	· · · · · · · · · · · · · · · · · · ·
83- 55	SCREW - set 5/16" - 18 x 5/16	"		····· "1».
192-23	LOCKWASHER - 1/2"			
" 1 29 - 105	NUT - 1/2'' - 13			
	-		а ү	
· ·	۰ ب		•	•
	. – .			-
`. ·				_
	•			, i
			,	
•		,		• • • •
•	· · · · ·		L.	
		L Contraction of the second		*
ана 1 1				
	· · · · ·	• •		
•	، ، ۱۰ مو	·	· .	· · · ·
				•
,	· ~		·• .	· · · ·
	(2)	н ^и ,		, · ·)

PUMP DRIVE CROSS SHAFT ٧١

📄 (1890, 1890K, 189	D	ľ				
---------------------	---	---	--	--	--	--

1 C 37770 PULLEY - 4" OD x 3/4" ID (use 8	
2 C 29581 KEY - 3/16'' x 3/16'' x 1''	
3 C 37773 BEARING - flanged (includes locki	na coll
4 C 37774 MOUNT - bearing L.H.	
5 C 37775 MOUNT - bearing R.H.	
6 C 37776* SPRING - extention	
7 C 37777 SHAFT - cross	
8 131- 911 NUT - 5/16 - 18 flange lock	
9 111-203 BOLT - 5/16" - 18 x 1" carriage	
10 C 37762 BELT - drive (1890, 1890K)	
10 C 24342 BELT - drive (1890V)	.,
11 C 45420 KIT - belt tension	
12 C 45123 TURNBUCKLE	
13 C 45146 SPACER	
14 113- 209 BOLT - 3/8'' - 16 x 1-1/2''	
15 129-, 103 NUT - 3/8'' - 16	
16 129-175 NUT -3/8'' - 16 L.H. threads	
17 131- 938 NUT - 3/8'' - 16 flange lock	
18 195-2029 WASHER	• • • •
	• • • •

(0)

(1)

23

 \sim

(15)

(16)

Ø Q Ø

(13)

(11)

 (\underline{n})

(14)


(18) (18)

(24)--

Can be replaced by C45420 belt tension kit.

																		,				RE	Q'E	;
5 set	sci	rev	N)	••				;											÷	<i>.</i>			3	
								. •		.'					0								3	
ollar)		۰.								1		-				,							2	
• • • •				. '																,			1	
																							1	
••••																							2	
																							1	
																							4	
																							4	
																							1	
																							1	
																							1	
,																							2	
 																							2	
 																							2	
																							2	
· · · ·																					7		2	
• • • •																								
• • • •											•			•	•	•	1	•	·	•			2	
••••	••	•••	·	•	•••	•	•	·	·	•	•	•	·	·	·	·	•	·	•	•			2	

DRIVE ASSEMBLY R.H. (1890, 1890K, 1890V)



25°

	ت		DRIVE ASSEMBLY R. (1890, 1890K, 1890V)
	REF.	PART NO.	DESCRIPTION
	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 24 25 26 27 28 9 30 31 22 33 45 56 37 38 34 35 36 37 38	C 37729 C 37730 C 37731 C 37732 132-332 C 37724 131-71 C 37725 195-102 C 37736 C 37736 C 37737 C 37738 C 37739 C 37740 C 37657 C 45399 C 37740 C 37657 C 45399 C $37742*$ C $45166**$ C 37743 C 37744 195-103 C 37744 195-103 C 37746 C 37747 192-20 129-102 C 37763 C 37652 C 37652 C 37652 C 37652 C 37652 C 37652 C 37652 C 37591 C 37591 C 37592 C 45272 C 45272 C 45773 218-5354 C 37756 C 37757 131-1102 C 37616	TRANSMISSION - ZT BAND - brake DRUM - brake RING - snap PIN - cotter 1/8" x 1" ROD - brake COLLAR - brake rod NUT - lock 1/4" - 20 SPRING WASHER - 1/4" SRACER RING - snap GEAR BEARING SPACER NUT - lug 1/2" - 20 PUMP - hydro R.H. (also use C45408 k LEVER - transmission dump LEVER - transmission dump LEVER - transmission dump R.H. BRACKET - dump lever stop SPRING - compression WASHER - 3/8" ARM - transmission BOLT - dump valve LOCKWASHER - 5/16" NUT - 5/16" - 18 WHEEL ASSEMBLY TIRE - 18 x 9.50 - 8 RIM - wheel BOLT - 5/16" - 18 x 1-3/4" BOLT - 5/16" - 18 x 7-1/2" LOCKWASHER - 3/8" NUT - 3/8" - 16. KEY - 5 x 5 x 25 mm PULLEY - 4" OD x 15 mm ID (1890, 18 PULLEY - 4" OD x 15 mm ID (1890, 18 PULLEY - 4" OD x 15 mm ID (1890V) (bu use C45474 shaft) -ADAPTER - 'ADAPTER - 'ADAPTER - 'ADAPTER - 1/4" NUT - 1/4" - 20 CLAMP - cable
	39 40	C 37615 113- 4	BUSHING - cable BOLT - 1/4" - 20 x 1"
1	41 42	C 37614 193-1000	BRACKET - cable end
	42 43 44 45 46 47 48 48 49 50	193-1000 NSS C 37761 C 37200 195-2063 195-520 113-203 113-267 192-21 129-103	NUT - lock #10 - 32 CABLE -*steering 58" (see page 49) BELT - pump drive BOLT - M6 - 1.0 x 12m flange WASHER625" x 1" (early production WASHER312" x .875" (early product BOLT - 3/8" - 16 x 3-1/2" mounting BOLT - 3/8" - 16 x 4" mounting LOCKWASHER - 3/8" NUT - 3/8" - 16
		, . . .	* Use before PIN:

** Use PIN and after: G1890 - 953404001 G1890K - 953403007 G1890V - 953403004

(26)

(44).

() ·	
· 2	REQ'D
·····	٦
	1
	1
	2
· · · · · · · · · · · · · · · · · · ·	1 '
	, 2
· · · · · · · · · · · · · · · · · · ·	1 2 1 2 1 5 2 1
· · · · · · · · · · · · · · · · · · ·	5
	<u> </u>
· · · · · · · · · · · · · · · · · · ·	1 1
	1
kit before PIN 953404001)	4. 1
	1
	1
· · · · · · · · · · · · · · · · · · ·	1 1
	1
	. 1
	4
· · · · · · · · · · · · · · · · · · ·	2. 1 `
	1
· · · · · · · · · · · · · · · · · · ·	1 2 2
	2
	1
· · · · · · · · · · · · · · · · · · ·	1 1
890K) before PIN 953407051 also	• 1
	, 1 ,
	1
head (early production)	• 1
	i,
••••••••••••••••••••••	3
	1
	1 1 •
	4
· · · · · · · · · · · · · · · · · · ·	1
·····	1 1
en)	UAR
ction)	1
· · · · · · · · · · · · · · · · · · ·	, 7
*************************************	8 . 8

	•	• • •				· · · · · · · · · · · · · · · · · · ·	ž,	DRIVE ASSEMBLY L.H. (1890, 1890K, 1890V)
		^				REF.	PART NO.	DESCRIPTION
	26 38 37 41 3 42 10 40 ALSO SEE PA	۵۲. ۱.				$ \begin{array}{c} 1\\ 2\\ 3\\ 4\\ 5\\ 6\\ 7\\ 8\\ 9\\ 10\\ 11\\ 12\\ 13\\ 14\\ 15\\ 16\\ 17\\ 18\\ 18\\ 19\\ 20\\ 21\\ 22\\ 23\\ 24\\ 25\\ 26\\ 27\\ 28\\ 29\\ 30\\ 31\\ 32\\ 32\\ 32 \end{array} $	C 37729 C 37730 C 37731 C 37732 132- 332 C 37733 C 37724 131- 71 C 37725 195- 102 C 37736 C 37736 C 37737 C 37738 C 37739 C 37740 C 45398 C 37740 C 45398 C 37740 C 45398 C 37742* C 45165** C 37742* C 37742* C 37742* C 37745 C 37744 C 37765 C 37744 C 37765 C 37746 C 37747 192- 20 129- 102 NSS 113- 120 113- 134 C 37591 C 37592 C 37592 C 37592 C 45272 C 45473	TRANSMISSION - ZT- BAND - brake DRUM - brake RING - snap PIN - cotter 1/8" x 1" ROD - brake COLLAR - rod NUT - lock 1/4" - 20 SPRING WASHER - 1/4" SPACER RING - snap GEAR BEARING SPACER PUMP - hydro L.H. (also use C45408 kit before BELT - pump drive LEVER - transmission dump LEVER - transmission dump L.H. BRACKET - dump lever stop SPRING - compression WASHER - $3/8$ " ARM - transmission BOLT - dump lever . LOCKWASHER - $5/16$ " NUT - $5/16$ " - 18 CABLE - steering 58" (see page 49) BOLT - $5/16$ " - 18 x 7-1/2" LOCKWASHER - $3/8$ " NUT - $5/16$ " - 18 x 7-1/2" LOCKWASHER - $3/8$ " NUT - $3/8$ " - 16 KEY - 5 x 5 x 25 mm PULLEY - 4" OD x 15 mm ID (1890, 1890K PULLEY - 4" OD x 15 mm ID (1890) (before
						33 34 35 36 37 38 39 40 41 42 41 42	218-5354 C.37755 C37756 192-19 121-101 C37616 C37615 113-4 C37614 193-1000 C37763 C37652 C37656 C37657 195-2063 C25178	use C45474.shaft) FITTING - male adapter FITTING - male adapter FITTING - male adaptor 90° SCREW - set $5/16'' - 18 \times 1/2''$ square head LOCKWASHER - $1/4''$ NUT - $1/4'' - 20$ CLAMP - cable BUSHING - cable BUSHING - cable BOLT - $1/4'' - 20 \times 1''$ BRACKET - cable end NUT - lock #10 - 32 WHEEL ASSEMBLY - not shown TIRE - $18 \times 9.50-8$ RIM - wheel NUT - lug $1/2'' - 20$ WASHER - $.625'' \times 1''$ (early production) WASHER - shim $.625'' \times 1'' \times .020''$
, , , , , , , , , , , , , , , , , , ,	· · · · ·				× · · · ·	45 46 47 47 48 49 50	195- 520 C 37200 113- 203 113- 267 192- 21 129- 103 C 38331	WASHER312'' x .875'' (early production) BOLT - M6 - 1.0 x 12 mm flange BOLT - 3/8'' - 16 x 3-1/2'' mounting BOLT - 3/8'' - 16 x 4'' mounting LOCKWASHER - 3/8'' NUT - 3/8'' - 16 FITTING - 90° male to female
•	•	۵ - -		•	· · · ·	- - - -	•	* Use before PIN: ** Use PIN and after: G1890 - 953404001 G1890K - 953403007 G1890V - 953403004
	•	• .	(27)		•			(28)

REQ'D 1 -1 . 2 . 1 2 1 e> 1 5 2 before PIN 953404001) **.**.... 2 ЭОК).... 1 efore PIN 953407051 also 1, 1 كالإدار والمتحج والمتحج والمتحج والمتح 1 ead (early production) 3 -1 1. 4 1 % 4 UAR -4 ion) 1 - 1 1 ٢ 7 8 8 ····· 11

-

۰.

C43293 STEERING CABLE KIT (1890, 1890K, 1890V) REQ'D 2 8 . Я 4 10 -..... 6 2 4 2 2 1 2 2 2 2 2 4. 2. 2 / 2 2 2 BRAKE ASSEMBLY 1800SS, 1800KSS 1 1 . . . 2 ••••••••

	· · · · ·	
	REF. PART NO.	DESCRIPTION
and the second s	1 C 42894 2 193-1000	CABLE - steering 46'' NUT - #10 - 32
()0, (18)	3 C +42895	BUSHING - steering cable
	4 111 111	BOLT - 1/4" - 20 x 1" carriage
	5 195-102	WASHER - 1/4"
(19)	6 131- 71	NUT - 1/4" - 10.
	7 113 4	BOLT - 1/4" - 20 x 1"
	8 C 42896	BRACKET - steering cable, end
	9 C 42897	LINK - control cable
	10 °C 42898	BELLCRANK
	11 C 16714	BUSHING
3)	12 C 42901	BRACKET - bellcrank mounting
	13 C 16745	BOLT - shoulder
	14 195- 533	WASHER - 1/2"
	15 131-1352	NUT - 3/8" - 16 flange lock
	16 113-103	BOLT - 5/16'' - 18 x 1''
	17 131-911	NUT - 5/16'' - 18
	18 113 4	BOLT - 1/4'' - 20 x 1''
	19 195- 102	WASHER - 1/4"
	20 C 42903	PLATE - cable mounting
	21 131- 71 22 ^{**} C 42902	
	,	BRACKET - cable mounting
معد ال	23 C 42904 24 C 34173	ARM - transmission
	24 C 34173	PIN - spring
• •	, P	,
· · · · ·		
	•	

10

10

11

12

13

14

15


16

[29]

	·	
C.	37719	MOUNT - brake
C '	37720	ROD - cross
С	37721	ROD - handle
С	37 <u>5</u> 78	-PIN - cross bar
Ċ	-37722	ROD - linkage
С	37723	ROD - caliper
С	37724	COLLER - rod
С	37,725	SPRING - caliper
С	37726	DISC - brake
С	37625 ·'	BRAKE CALIPER - R.H.
.C	37626	BRAKE CALIPER - L.H.
С	37627	PUCKS - brake
С	37604	LEVER - brake
С	37631	GRIP - lever
С	37630	TAB - lever stop
Ċ	37728	MOUNT - switch
С	37521	SAFETY SWITCH ,
	. '	

WHEEL MOTOR & PUMP ASSEMBLY


				IMP ASSEN	IBLY 🐘		ï
	· · ·	ri a , tin stati (1800\$\$, 180	DOKSS)	, " " , y " "		
F.	PART NO.	DESCRIPTION					REQ'D
	C 37632 C 37633 C 37634 C 37635 C 37636 C 37636 C 37637 C 37639 C 37640 C 37640 C 37641 C 37642 C 37643 C 37644 C 37645 C 37646 C 37646 C 37647 C 37648 C 37648 C 37649 C 37650 C 37650 C 37650 C 37653 C 37655 C 37655 C 37656 C 37657 C 37657 C 37658 C 37657 C 37658 C 37660 C 37661 C 37663 C 37665 C 37665 C 37665	WHEEL MOTOR - I WHEEL MOTOR - I MODEL 7 PUMP - MODEL 7 PUMP - HOUSING - Oil Filt ELEMENT - Oil Filt TANK - oil, 3 qt. CAP - Oil Tank FITTING - male tut FITTING - male or FITTING - male or HOSE - 1/2". ID x HOSE - 1/2". ID x HOSE - 1/2" ID x	R.H. L.H. R.H. er er be, Male O-rir be, 90° Fema ing, 90° Male ing, 90° Male 28'' Long 24'' Long, Ea 3-3/4''	ng Adp. Ile Pipe Swive e Tube Adp. se Barb Tee e Tube Adp. asy Couple , Easy Couple , Easy Couple asy Couple Jse with 42"	I Adp.		$ \begin{array}{c} 1\\ 1\\ 1\\ 1\\ 1\\ 1\\ 8\\ 2\\ 1\\ 1\\ 2\\ -\\ 2\\ -\\ 8\\ 2\\ 1\\ 8\\ 2\\ 2\\ 1\\ 8\\ 2\\ 2\\ 2\\ 2\\ 2\\ 2\\ 2\\ 2\\ 2\\ 2\\ 2\\ 2\\ 2\\$
		· · · · · · · · · · · · · · · · · · ·				e e	
t -						te a	
•		· · · · ·			· ·		، ، ، ، ، ، ،
			· · · · ·	•		· · ·	
s ,		•		ب ' ۲ ه			•
		· ·	•,	-			_ ·







WHEEL MOTOR & PUMP ASSEMBLY 2000



33)

		•		
RT NO.	DESCRIPTION	· · ·	· · ·	REQ'D
37667	WHEEL MOTOR			. 2
37668	PUMP - L.H. CW (Eaton No. 1120-004	H) 🔬		. 1
44376	PUMP - L.H. CW (Eaton No. 1120-016	5)		. 1
37669	PUMP - R.H. CCW (Eaton No. 1120-00	05)	· · · · · · · · · · · · · · · · · · ·	. 1
44375	PUMP [®] - R.H. CCW (Eaton No. ⁹ 1120-01	17)		. 1
37670	HYDRAULIC OIL TANK			1
37671	HOSE CLAMP			. 2
37672	HYDRAULIC FILL CAP ASSEMBLY			. 1 (
37673	GASKET	. 		/
3,7674	STRAINER			
3 7675 ·	FILL NECK			· · · · ·
38310	BREATHER CAP			
8-5146	FITTING - male tube, 45° male o-ring a	adapter ,	• .	. 3
37678	FITTING - special cross			1
37679 1	SPECIAL ADAPTER			
37680	FITTING - male tube, 90° female swive	el adapter		. 1
8- 5057	FITTING - male tube, male o-ring adapt	ter		. 4 '
8- 5060	FITTING - male tube, male o-ring adapt			
8-5121	FITTING - male tube, 90° male o-ring a	adapter 📖 📖	 . <u>.</u>	1
8-5175	FITTING - male tube, 45° female swive	el adapter		. 1
8-5103	FITTING - male tube, 90° male o-ring a	adapter		. 1
8- 5478	FITTING - male tube, female swivel tee	9		. 1
37686	FITTING - male tube, 45° female swive			
37,687	HOSE - 1/2" ID x 18" long, easy coup	ole •		. 1
37688	HOSE - 1/4" ID x 14" long, easy coup	ole		1
37689	HOSE - 1/4" ID x 20" long, easy coup	ole		1, ,
37690*	HOSE - 1/2" ID x 36 1/2" long (3/4"	threads at pur	np)	4
44465*,*	HOSE - 1/2" ID x 36-1/2" (7/8" threa	id at pump)	· · · · · · · · · · · · · · · · · · ·	4
37691	HOSE - 3/4" ID x 22" long, easy coup	ole	•••••	1
37692	HOSE - 3/4" ID x 18" long, easy coup	ole		. 1
37693	HOSE - 1/2" ID x 20" long, easy coup	ole	• • • • • • • • • • • • • • • • • • • •	1
8-5173	FITTING - 45° 3/4" - 16 x 3/4" - 16	. 		1 *

34

* Use with pumps, Eaton No. 1120-004 and 1120-005 *** Use with pumps, Eaton No. 1120-016 and 1120-017

; .	HYDRAULIC SYSTEM (1890, 1890K, 1890V)		- ·
PART NO.	DESCRIPTION	· · · ·	REQ'D
PART NO. 131- 69 195- 103 113- 119 C 45495 C 37769 C 37639 C 37772 C 37778 214- 254 C 37637 C 37636 C 42785 C 42784 C 42784 C 42784 C 42784 C 42784 C 42784 C 42784 C 42784 C 37642 C 37785 214- 274 C 37787 113- 3 195- 102 131- 1102 131- 934 C 41931 192- 19 C 41986 C 32455 113- 102	DESCRIPTION NUT - lock $5/16''$ WASHER - $5/16'' - 18 \times 2 \cdot 3/4''$ BUSHING - rubber COOLER - oil CAP - oil tank MOUNT - oil cooler TANK - oil CLAMP - hose $5/8''$ FILTER - oil HEAD - oil filter HOSE - $5/8'' \times 11''$ ($12''$ cut to length) HOSE - hydraulic $3/8'' \times 13''$ ($48''$ cut to length) HOSE - hydraulic $3/8'' \times 25''$ ($48''$ cut to length) HOSE - hydraulic $3/8'' \times 27''$ ($48''$ cut to length) HOSE - hydraulic $3/8'' \times 27''$ ($48''$ cut to length) HOSE - hydraulic $3/8'' \times 27''$ ($48''$ cut to length) HOSE - hydraulic $3/8'' \times 24''$ ($48''$ cut to length) HOSE - hydraulic $3/8'' \times 24''$ ($48''$ cut to length) HOSE - hydraulic $3/8'' \times 24''$ ($48''$ cut to length) HOSE - hydraulic $3/8'' \times 24''$ ($48''$ cut to length) HOSE - hydraulic $3/8'' \times 24''$ ($48''$ cut to length) HOSE - hydraulic $3/8'' \times 38''$ ($48''$ cut to length) HOSE - hydraulic $3/8'' \times 24''$ ($48''$ cut to length) HOSE - hydraulic $3/8'' \times 38''$ ($48''$ cut to length) HOSE - hydraulic $3/8'' \times 38''$ ($48''$ cut to length) HOSE - hydraulic $3/8'' \times 38''$ HOSE - hydraulic $3/8'' \times 38'''$ HOSE - hydraulic $3/8'' \times 38'''$ HOSE - hydraulic	pth) pth)	REQ'D 1 1 2 2
113- 102 131- 911 C 38794 C 37807 113- 1 C 42590	BOLT - 5/16" x 18 x 3/4" NUT - 5/16" - 18 flange lock FITTING - 5/8" hose barb x 1/2" FM JIC MOUNT - oil tank BOLT - 1/4" - 20 x 1/2" FITTING - 90°	· · · · · · · · · · · · · · · · · · ·	1 1 1 4 2
		· · · ·	
			- - -
,			· · ·
,~∳-`			
• • •	۰. ۱		· · ·
÷			ۍ -
• •		• • •	

36

(22) 8 ٩ (29) (28) 31)-(30) (12) . (15) 14-(28) (21) . 32 [11](27) (26) (20) (2)(1) (16)(3)

(34)-

(25

23)

(13)

(28)

(6)

٩m

(35

REF.

9

HYDRAULIC LIFT ASSEMBLY (2000) (original equipment with dual acting lift cylinder) (Also see below)

REF.	PART NO.	DESCRIPTION
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15	C 37788 C 37789 C 37607 C 37790 C 37791 C 37792 C 37793 C 37636 C 37636 C 37637 C 37794 C 37795 C 37796 C 37797 C 37798 C 37799	MOUNT - valve VALVE LEVER BEARING - clutch brake cross rod SUPPORT - valve CONNECTING LINK - #50 VALVE LIFT CYLINDER HOUSING - oil filter ELEMENT - oil filter HOSE - 3/8" ID x 26" long HOSE - 3/8" ID x 31" long HOSE - 3/8" ID x 31" long HOSE - 3/8" ID x 13" long HOSE - 3/8" ID x 13" long HOSE - 3/8" ID x 13" long HOSE - 3/8" ID x 11.5" long HOSE - 3/8" ID x 21" long
16 [/] 17		 FITŢING - male o-ring, 90° male tube adp.
16 ⁷	C 37755	 FITŢING - male o-ring, 90° male tube adp.
17 18 19	C 37681 C 37800 C 37785	FITTING - male o-ring, male tube adp FITTING - male o-ring, 90° male tube adp. FITTING - male tube, male o-ring tee

8 9

(10)

(19)

	HYDRAULIC LIFT ASSEMBLY (2000) (with single acting lift cylinder)
C 37788	MOUNT - valve
C 37789	LEVER - actuator
C 37607	BEARING
_ C * 37790	SUPPORT - valve
_ C_ 37791	CONNECTING LINK - #50
C໌ 42937	VALVE - lift
C 44030	CYLINDER - lift
C 37636	HOUSING - oil filter
C 37637	ELEMENT - oil filter
C 37794	HOSE - 3/8" ID x 26" long
C 37795	HOSE - 3/8" ID x 31" long
C 37796	HOSE - 3/8" ID x 20" long
、C 37797	HOSE - 3/8" ID x 13" long
°C 37798	HOSE - 3/8" ID x 11.5" long
C 37799	HUSE - 3/8" ID x 21" long
218-5278	FITTING - 90° male tube adp
218-5057	FITTING - straight
218-5128	FITTING - tee
218-5182	FITTING - tee
218-5105	FITTING - straight
218-5058	FITTING - straight
218-5059	FITTING - straight
C 44636	HOSE - 1/2''
°C 37671	CLAMP - hose
C 44193	FITTING - tee
C 42935	BREATHER
°C *42936	FITTING - adaptor (if required)
218-980	FITTING - 90°
218-5173	FITTING - 45° swivele.
C, 44506	HOSE - 1/2" x 10" to L.H. Pump
C 44508	HOSE - 1/2" x 4-1/2" to R.H. Pump

(2)(5)(6) (29) (16) Co.P (19` 1 (14)

(37)

1

13-

19

10 62

16

3.

		•																								F	RE	Q	D
				•			-			•					,						-	1		•	•		•	.1	
•	•	-	•	-	•	,	•	•	•	•	•	•		•	:	•	•	÷	•	•	٠	•	•	•	•			1	Р
٠	•	•	•	•	·	۰.	•	•	·	•	·	·	•	•	•	•	•	•	•	•	·	•	•	•			•	1.	
•	·	•	•	•	•	'	•	·	•	•	·	•	•	•	•	•	٠	·	•	·	·	•	•	2				1	
	ļ	Ĵ		•		1	ł		:			:	•	•	•	:	•	•	•	•	•	•	•	•				1	
				•		,	2					;										:		•				1	,
	-	٠.	•	-	•		ł	•		•		I.		•			•		•		•			•				1	
·	·	•	·	•	·	•	·	·	•	•	·	·	•	·		•	٠	•	;	•	•	•	·	·				1	
•	•	•	•	•		·	•	•	• •	·	·						•							•		٢		229 1	
		;			•		:										•					•	•	•	•	4		1	
						ż	÷						÷	:			•					-						1	
•	•			•	•	•	•	•	•	•		•	•	•	•	•	•	•	•	•		-	•	•.	•			1	
		•	•	•	•	• '	-	·	·	•	·	·	•	•	·	·	•	·	•	•	•	•	•	·				1	
p	•	•	•	•	•	•	•	•	•	•	•	•					•		•	•	•	•	•	•				2	;
p	Ċ													•				•	:	•				•		·		1.	
						Į	٠					•	ł								•		÷	•				2	
						•													•						,		•		

ELECTRIC DECK LIFT (1890, 1890K, 1890V - Optional) WINCH

Ower Lift REF PART NO. DESCRIPTION REC'D 1 13.207 BQLT: 348-7 16 x 1". 6 6 2 C 34393 SCREW 397-16 x 1". 6 6 3 C 43987 MOUNT - wine Thank to k 7 6 4 C 43987 MOUNT - wine Thank to k 7 6 4 C 43987 MOUNT - wine Thank to k 7 7 6 C 43987 MOUNT - wine Thank to k 7 7 6 C 43986 MOUNT - wine Thank to k 7 7 7 T 31.33 C A43964 C A43964 7 7 9 C 4 43964 SROMMET - 114" - 20 x 1/2" 3 7 7 1 10 C 4 43964 SROMMET - 114" - 20 x 1/2" 3 3 1		4	1 - j	4 - I	WINCH	1
$ \begin{array}{c} 1 & C & 44439 \\ 2 & 131 - 338 & NUT - 387 \cdot 16 \ flange \ lock \\ 3 & C & 43967 \\ 4 & C & 43956 \\ 4 & C & 43957 \\ 6 & C & 43975 \\ 6 & C & 43975 \\ 6 & C & 43975 \\ 6 & C & 43972 \\ 8 & 131 - 33 \\ 8 & 0UT - 144' - 20 \ s147' \\ 133 \\ 133 \\ 4 & 0UT - 144'' - 20 \ s147' \\ 11 \\ 113 $	neuron Lilt	REF.	PART NO.	DESCRIPTION	·	REQ'D
$\begin{array}{cccccccccccccccccccccccccccccccccccc$	(3)	11 12 13 14 15 16 17 18 19 20 21	C 44489 131- 938 C 43967 C 43958 C 43375 C 43992 113- 3 131- 934 C 43962 C 43964 113- 1 C 43963 113- 219 131- 1352 C 43961 C 43961 C 43960 C 43412 193- 1000 C 44361 C 44364 C 44364	SCREW - $3/8'' - 16$ NUT - $3/8'' - 16$ flan MOUNT - winch WINCH - deck lift CABLE PIN - cable keeper BOLT - $1/4'' - 20 x$ NUT - $1/4'' - 20$ flan COVER - solenoid . GROMMET - $1'' x 7/$ BOLT - $1/4'' - 20 x$ MOUNT - solenoid . BOLT - $3/8'' - 16 x$ NUT - $3/8'' - 16 x$ NUT - $3/8'' - 16 loclSPACERSTRAP - liftDECAL - ''Power LiftNUT - #10 - 32ARM - tripMOUNT - trip armPIN - pivotPIN - cotter 1/16'' x$	x 1" socket head	6 2 8 1 1 1 2 5 1 1 3 1 1 1 1
		•	C 43966 C 43983 193-1000 C 43969 129-101 192-19 113-1 131-934 113-3 C 43965 C 33744 C 43985 C 44495	SOLENOID - 12V STRAP BREAKER - 40 amp, NUT - #10 - 32 HARNESS - wire NUT - 1/4'' - 20 LOCKWASHER - 1/4 BOLT - 1/4'' - 20 x NUT - 1/4'' - 20 x BRACKET - switch SWITCH - 1imit SWITCH - 1ift DECAL - switch iden	12V 1/2'' 1/2'' 3/4'' itification	1 2 1 8 8 8

(10-0

(9)

(3)

(18)-9

(14

۵

(8)

 (\mathbf{n})

-(11)

1

-6

(8)


(14)

A

39

6

(40)



-	
PART NO.	DESCRIPTION
o 40044	• • • • •
C 42241	HARNESS - wire (2000) HARNESS - wire (1890V)
C 44265	HARNESS - Wire (1890V)
C 37532	HARNESS - wire (1800SS, 1800KSS, 1890
C 37505	
NSS	HEADLIGHT - (use C32178 and C44075) .
C 37511	CLUTCH - PTO, electric
C 31937	SWITCH - PTO
C 43044	SWITCH - headlight RELAY BOLT - 1/4" - 20 x 3/4" (relay mounting)
C 37515	RELAY
113- 3	BOLT - 1/4" - 20 x 3/4" (relay mounting)
່ 192- 19ູ	LOCKWASHER - 1/4" (relay mounting)
121- 101	NUT - 1/4" - 20 (relay mounting)
C 24145	SWITCH - ignition
C 32407	KEY - ignition
C 32397	CAP - nut
193- 63	LOCKWASHER - 5/8"
C 32396	NUT - 5/8'' - 32
C 37517	AMMETER
C 37518	METER - hour
C 37519	LIGHT - oil
C 37520	SWITCH - seat
C 37521	SWITCH - safety (enlarge mounting hole if r
i C 41010	BATTERY - 12 volt
C 37523	BATTERY - 12 volt
C 38840	WIRE - starter (2000)
C 44261	WIRE - starter (2000)
C 37528	CABLE - ground
C 44075	WIRE - headlight
C 37526	SOLENOID - starting .
113- 3	BOLT - 1/4" - 20 x 3/4" (solenoid mounting
192-19	LOCKWASHER- 1/4" (solenoid mounting)
129- 101	NUT - 1/4" - 20 (solenoid mounting)
192- 20	LOCKWASHER - 5/16" (solenoid studs)
129- 102	NUT - 5/16" - 18 (solenoid studs)
192- 18	LOCKWASHER - 3/16" (solenoid studs)
129- 37	NUT - #10 - 32 (solenoid studs)
129 - 6	NUT - #8 - 32 (solenoid studs)
ິC 37523	WIRE - battery positive to solenoid
C 37529	ACTUATOR - electric lift (early production) (
C 37530	SWITCH - deck lift (early production) (also s
C 37531	SWITCH - deck int (early production) (also s
C 22573	SWITCH - oil light LENS - headlight
C 37508	PULP boodlight
C 37509	BULB - headlight
C 14304	RECEPTICAL - headlight
	GASKET - headlight
113- 4 129- 101	BOLT - 1/4'' - 20 x 1'' NUT - 1/4'' - 20
C 37835	$\mathbf{PDACKET} = \mathbf{bettem} = \mathbf{b} = \mathbf{b} + \mathbf{c} + c$
C 37983 .	BRACKET - battery hold down (2000)
	BRACKET - battery hold down (1800SS, 180
	BOLT - 1/4" - 20 x 7"
131- 71	NUT - 1/4" - 20 lock
195-102	WASHER - 1/4"
113- 3	BOLT - 1/4'' - 20 x 3/4''
131- 934	NUT - 1/4" - 20 flange lock
C 37809	PROTECTOR - battery post (early production
C 41643	WIRE - engine ground
129- 101	NUT - 1/4" - 20.
C 24069	CUVER - terminal
C 43048	HORN - warning (1890V)
, ~o	· " ,

۴.,

(42)

REF.

2

3

6

7

8

9

10

11

14 15 16

17

24

29

37


38

WIRING DIAGRAM

		1		
			. (
1	· · ·		,	-
		е н. А	1.8	
· · · ·	ବ	86	ΏΩ ́	
, ,	•			
			1	
		• • • · · ·	1	
390, 1890K)		•••	1	5
		~ ~	1	•
)			2.	
	,` `		1	
			1	
			1	
	î î i și		1	
))		••	1	
		• • *	1	•
		• • •	1	•
• • • • • • • • • • • • • • •		• •	1	
		**	2	
· · · · · · · · · · · · · · · · · · ·			1	
	.		1 ·	
· · · · · · · · · · · · · · · · · · ·			1	
			1	
	. 		1	
· · · · · · · · · · · · · · · · · · ·			1.	
			1	
if required)			2.	
• • • • • • • • • • • • • • • • • • • •			1	
		21 ·	1	
		• •	1	
		• -	1	
• • • • • • • • • • • • • • • • • • • •			1	
· · · · · · · · · · · · · · · · · · ·	Š.,	¹	1	
• • • • • • • • • • • • • • • • • • • •	المتعاقبة والمتعالية والمناطقة والمناطقة والمناطقة والمناطقة والمناطقة والمناطقة والمناطقة والمناطقة والمناطقة		1	1
		••	2	
g) <u>.</u>		• •	2	
		••	2 2 2 2	
··· · · · · · · · · · · · · · · · · ·			2	
• • • • • • • • • • • • • • • • • • •	يشتنت	ار جن	2	
· · · · · · · · · · · · · · · · · · ·			2	
s A		•••	1	
	• • • • • •	· · ·	1	
		· · · ·	1	
n) (also see page 59)/	, , , , , , , , , , , , , ,	•• ;'	1 1	•
o see page 59)			1	
· · · · · · · · · · · · · · · · · · ·		• • • •	1 2 2 2 2 2 2 2	
• • • • • • • • • • • • • • • • • • • •		• •	2	
••••••••••••••••••••••••••••••••••••••	· · · · · · · · · · · ·	• •	2	
• • • • • • • • • • • • • • • • • • • •		••	2	
		· ·	2	
ز	• • • • • •	•••	2	
· · · · · · · · · · · · · · · · · · ·	••••	•••	2.	
1800KSS, 1890, 1890		 	1,	ŝ
1800KSS, 1890, 1890	ж, авяо	PV)	1	
· · · · · · · · · · · · · · · · · · ·	- <i>i</i> ii	• г <u>а</u>	2	
· · · · · · · · · · · · · · · · · · ·	•••••	•• •	4 3 3 1	
			3	
· · · · · · · · · · · · · · · · · · ·			3	
· · · · · · · · · · · · · · · · · · ·	• • • • • • •	•••	1	۰.
tion)	·····	• •	1	
· · · · · · · · · · · · · · · · · · ·	• • • • • • •	• •	1	
	· • • • • •		<u>∠</u> `	
	• • • • • •	• -	1	
		• •	I	•
-		1. I		
. 3			•	
• •				0
- 4				

.... 8 . . .

DECALS (TRACTOR)



<u>,</u> •			••••
REF. '	PA	RT NO.	DESCRIPTION
1	· .C	44062	DECAL - body side ''G1890'' L.H.
1	C	44063 [`]	DECAL - body side "G1890" R.H. (show
<u></u> 2.	C	44064	DECAL - body side "G1890K" L.H.
2	C	44065	DECAL - body side "G1890K" R.H. (sho
3	C,	37501	DECAL - instrument panel
ʻ4		38047	MEDALLION - "GRAZER"
5	٢C	37495	DECAL - operation
6	С	37496	DECAL - caution interlock
7	Ċ	37502	DECAL - unlock/lock
8.	ÆE	37498	DECAL - run/park (1800C)
, 9 ^ `	٣C	37500	DECAL - "danger" carbon monoxide
10	С	38807	DECAL - lubrication
11 👘	, C	37504	DECAL - clean cooler
12	· C ੈ	43417	DECAL - fender skirt L.H.
12	С	43418、	DECAL - fender skirt R.H. (shown)
13.	ູເ	43413	DECAL - front "GRAZER"
14	Ċ	43416	`DECAL - tail side "GRAZER"
15	C	43993	DECAL - body side "G1890V" L.H.
15	С	43994	DECAL - body side "G1890V" R.H. (sho
•	С	-38101	KIT - decal (1890) (includes ref. 1, 12, 1
	С	38102	KIT - decal (1890K) (includes ref. 2, 12,
	С	38099	KIT - decal (1800SS) not shown
	°C	37512	KIT - decal (1800KSS) not shown
•	С	38100	KIT - decal (2000) (includes ref. 12, 13,
18	С	44210	DECAL - R.H. body side "G2000CII" (sh
18		44211	DECAL - body side "G2000CII" L.H.
19		44551	DECAL - "Fuel Only" (2000)
20		37499	DECAL - "Hydraulic Oil" (2000)
21		37503	DECAL - hydraulic valve (2000)
22	C	• 44340	DECAL - warning

. (44)

REQ'D 1 <u>vn)</u> own) . '1 hown).....